

4x6,5L-R



700228

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

Phone: +49 5258 971-0

Fax: +49 5258 971-120

Technical Support Hotline: +49 5258 971-197

www.bartscher.com



Version: 2.0

Date of preparation: 2024-10-11

Original instruction manual

1	Safety	2
1.1	Explanation of Signal Words	2
1.2	Safety instructions.....	3
1.3	Intended Use	6
1.4	Unintended Use	6
2	General information	7
2.1	Liability and Warranty	7
2.2	Copyright Protection	7
2.3	Declaration of Conformity	7
3	Transport, Packaging and Storage	8
3.1	Delivery Check.....	8
3.2	Packaging	8
3.3	Storage	8
4	Technical Data.....	9
4.1	Technical Specifications	9
4.2	Functions of the Appliance.....	10
4.3	List of Components of the Appliance	11
5	Installation and operation	12
5.1	Installation.....	12
5.2	Operation	13
6	Cleaning	15
6.1	Safety Instructions for Cleaning	15
6.2	Cleaning.....	16
7	Possible Malfunctions.....	17
8	Disposal.....	18



Read these instruction manual before using the appliance and keep it available at all times!

This instruction manual contains information about installation, operation and maintenance of the appliance and constitutes an important source of information and reference guide. The knowledge of all operational and safety instructions included in this manual is a prerequisite for safe and proper handling of the appliance.

Read this instruction manual before you use the appliance and particularly before you start the appliance to prevent injury or damage. Incorrect use may cause damage.

All important information contained in the operating instructions must be available to the appropriate staff at all time. The operator shall be responsible for their availability.

In addition to the operating instructions, you must comply with the general, legal and other applicable regulations for occupational safety and environmental protection.

EN

1 Safety

This appliance has been manufactured in accordance with technical standards currently in force. However, the appliance may be a source of hazards if used improperly or contrary to its intended purpose. All persons using the appliance must consider information included in this instruction manual and observe safety instructions.

1.1 Explanation of Signal Words

Important safety instructions and warning information are indicated in this instruction manual with appropriate signal words. You must strictly follow the instructions, to prevent accidents, personal injuries and property damages.



DANGER!

The signal word **DANGER** warns against hazards that lead to severe injuries or death if the hazards are not avoided.



WARNING!

The signal word **WARNING** warns against hazards that may lead to moderate or severe injuries or death if the hazards are not avoided.



CAUTION!

The signal word **CAUTION** warns against hazards that may lead to light or moderate injuries if the hazards are not avoided.

IMPORTANT!

The signal word **IMPORTANT** indicates possible property damages, which may occur if safety instructions are not observed.

NOTE!

The symbol **NOTE** indicates subsequent information and guidelines for the user on usage of the appliance.

1.2 Safety instructions

Electrical Current

- Too high a mains voltage or incorrect installation may cause electric shock.
- The appliance may be connected only if data on the rating plate correspond with the mains voltage.
- To avoid short-circuit, the appliance should be kept dry.
- If there are malfunctions during operation, disconnect the appliance from the power supply.
- Do not touch the appliance's plug with wet hands.
- Never take hold of the appliance if it has fallen into water. Immediately disconnect the appliance from the power supply.
- Any repairs or housing opening may be carried out by professionals and relevant workshops only.
- Do not transport the appliance, holding it by the power cord.
- Do not allow the power cord to come into contact with heat sources or sharp edges.
- Do not bend, pinch nor knot the power cord.

- Always completely unwind the power cord.
- Never place the appliance or other objects on the power cord.
- Always take hold of the plug to disconnect the appliance from the power supply.
- Check the power cord regularly for damage. Do not use the appliance if the power cord is damaged. If this cable is damaged, it must be replaced by customer service or a qualified electrician in order to avoid dangers.

Fire hazard / flammable materials hazard / explosion hazard!

- Do not use any electric devices in the appliance.
- Do not store nor use petrol or other flammable liquids and gases in the vicinity of this or any other appliance. Those gases may cause fire or explosion hazard.
- Do not put into the appliance any explosive materials, like sprays filled with flammable propellants. Contents of containers filled with flammable gases and liquids may leak in low temperatures, and the contents may catch fire from sparks generated by an electric appliance. Explosion hazard!
- In the case of coolant leakage, pull the plug from the socket. Remove all sources of ignition in the vicinity, ventilate room and contact technical service. Avoid coolant getting in contact with eyes, as it may cause serious eye damage.
- Never use any flammable liquids for cleaning the appliance or its parts. Gases released may cause fire or explosion hazard.
- In the case of fire, disconnect the appliance from the power supply before attempting adequate fire-extinguishing actions.
- Never attempt to extinguish fire with water if the appliance is connected to the power supply. Following extinction of fire, ensure sufficient fresh air inflow.
- Defrosting process may not be sped up with mechanical means or heat energy sources (candles or heaters) nor with any other means. Vapour produced may cause short-circuit and too high temperatures may damage the appliance.
- All ventilation slots should not be obstructed during operation.
- Never attempt to damage cooling installation of the appliance.

Operating Personnel

- The appliance may only be operated by qualified personnel and trained specialist personnel.
- This appliance may not be operated by persons (including children) with limited physical, sensory or mental capabilities, nor by persons with limited experience and/or limited knowledge.
- Children should be supervised to ensure that they are not playing with or switching on the appliance.

Improper Use

- Unintended or prohibited use may cause damage to the appliance.
- The appliance may only be used when its technical condition is flawless and allows for safe operation.
- The appliance may only be used when all connections are executed according to rules of law in force.
- The appliance may only be used when it is clean.
- Use only original spare parts. Never attempt to repair the appliance on your own.
- Do not introduce any changes in the appliance nor modify it.

- Do not drill hole in the appliance nor install any objects on it.
- Do not place any heavy objects on the appliance.

1.3 Intended Use

This appliance is only intended for use described in the operating instructions, with the supplied and approved components.

Any other use is considered against the intended purpose. The manufacturer shall not be liable for any damage due to unintended use. In such cases the responsible party shall only be the user/operator.

The following is an intended purpose:

- Storing ice cream for on-going preparation of desserts in professional kitchens.

1.4 Unintended Use

An unintended use may lead to personal injuries or property damages caused by hazardous voltage, fire or high temperature. The appliance may only be used to perform tasks described in this instruction manual.

The following is an unintended use:

- prolonged storage of ice cream;
- Storing flammable or explosive objects and liquids, such as ether, petroleum or adhesives;
- Storing explosive materials, like sprays filled with flammable propellants;
- Storing pharmaceutical products or preserved blood;
- Storing live pets.

2 General information

2.1 Liability and Warranty

The appliance was built in accordance with the current state of the art and recognized technical safety principles. Nevertheless, during its use, there may be a threat to the health and life of the user or bystanders, or the danger of damage to the device or other assets. Warranty and liability claims for personal injury/property damage as well as defects at work are excluded if they can be attributed to one or more of the following causes:

- Use against the intended purpose
- Failure to follow/disregard the instructions and all related information
- Unauthorized structural or technical changes to the device
- Engaging insufficiently trained and insufficiently qualified personnel
- Operation with defective or incorrectly installed safety and protective devices
- Inadequate maintenance or cleaning
- Faults not fixed
- Use of prohibited media, cleaning agents, etc.
- Use of unauthorised spare parts
- Errors in operation or other misuse
- Disasters caused by foreign objects or force majeure
- Destruction of the type plate and stickers relevant for operation and safety

The warranty period for this appliance is 24 months, counted from the purchase date.

2.2 Copyright Protection

This instruction manual, and texts, drawings and images included in it, as well as its other components are copyright protected. It is prohibited to reproduce this instruction manual (including its excerpts), in any form and by any means, and to use and/or transfer its content to third parties without manufacturer's written permission. Violation of the above results in obligation to pay compensation. We reserve the right to claim further damages.

2.3 Declaration of Conformity

The appliance meets the currently applicable standards and guidelines of the European Union. We confirm the above in the EC Declaration of Conformity. We may provide relevant Declaration of Conformity upon request.

3 Transport, Packaging and Storage

3.1 Delivery Check

Immediately upon reception, check the delivery for completeness and possible shipping damage. In the case of visible transport damage refuse to accept the appliance or accept it conditionally. Mark and note the scope of damage in shipping documents/consignment list of the shipping company and lodge a complaint.

Concealed damage must be reported immediately upon its discovery, as compensation claims may only be filed within applicable time limits.

If you find that parts or accessories missing, please contact our Customer Service Department.

3.2 Packaging

Do not dispose of the appliance cardboard box. It may be used to store the appliance when relocating or when shipping the appliance to our service point in the case of any damages.

The packaging and its elements are made of recyclable materials. Particularly, these are: plastic films and bags, cardboard box.

When disposing of the packaging, observe applicable domestic regulations. Recyclable packaging materials should be recycled.

3.3 Storage

Leave the packaging closed until installation of the appliance; observe external indications concerning method of placing and storage. Store the packaging in the following conditions only:

- in closed rooms;
- in dry and dust-free surrounding;
- away from aggressive agents;
- in a location protected against sunlight;
- in a location protected against mechanical shocks.

In the case of extended storage (over three months), make sure you check the condition of the packaging and the parts regularly. If needed, replace the packaging with a new one.

4 Technical Data

4.1 Technical Specifications

Name:	Ice cabinet 4x6,5L-R
Art. No.:	700228
Material:	stainless steel
Volume max., in l:	26
Capacity max.	4 ice cream containers, 6.5 litres each
Depth container max. in mm:	150
Temperature range, min.–max., in °C:	-18 – -25
Coolant / amount, in kg:	R290 / 0,056
Climate class:	4
Energy efficiency class:	F (EU Nr. 2019 / 2018)
Energy consumption in kWh / an:	1631
Degree of protection:	1
Power supply:	0,168 kW 220-240 V 50 Hz
Dimensions (W x D x H) in mm:	805 x 665 x 350
Weight in kg:	33,4

We reserve the right to implement technical modifications!

Version / Characteristics

- Designed for use in kitchens
- Type of glazing: double glazing, safe glass
- Front pane: rounded, cased / framed
- Door type: lifting door
- Door position: rear side
- Door hinge: top
- Temperature control: thermostatic, electronic
- Control: button
- Digital display
- ON/OFF button
- Indicator light: ON/OFF
- The set includes:
 - 4 ice cream containers, 5 litres each, W 360 x D 165 x H 100 mm, stainless steel
 - 3 bars, length 365 mm, width 20 mm

EN

More information on the appliance is available in our website www.bartscher.com or, pursuant to the Regulation (EU) 2019/2018, in our product data base at <https://energy-label.ec.europa.eu/>. Enter article number for a given model.

4.2 Functions of the Appliance

The ice cabinet is designed for storing ice cream for preparation of desserts in professional kitchens.

4.3 List of Components of the Appliance



EN

Fig. 1

- | | |
|------------------------|----------------------------------|
| 1. Glass lid | 2. Glass lid handle |
| 3. Lid damper (2 pcs.) | 4. Ice cream containers (4 pcs.) |
| 5. Display surface | 6. Adjustable feet (4x) |
| 7. Ventilation slots | 8. Digital temperature regulator |
| 9. ON/OFF switch | 10. Power cord |
| 11. Housing | |

5 Installation and operation

5.1 Installation

Unpacking / Positioning

- Unpack the appliance, remove all external and internal packaging elements and shipment safeguards.



CAUTION!

Choking hazard!

Prevent children from accessing packaging materials, for instance: plastic bags and EPS elements.

- If the appliance is covered with a protective film, remove it. Remove the film slowly, so no glue residues are left. Remove any glue residues with the use of a suitable solvent.
- Be careful not to damage the rating plate and warning labels affixed to the appliance.
- **Never** place the appliance in humid or wet environment.
- Place the appliance in a way making the connections easily accessible, so that they may be quickly disconnected if such a need arises.
- When selecting the installation site, please consider the following items:
 - The mounting surface must be even, sufficiently load-bearing, waterproof, dry and resistant to high temperatures.
 - Make sure that the designated escape routes are clear.
 - Ensure a stable position.
 - Allow sufficient space for work, maintenance and cleaning.
 - Leave the supply and exhaust air vents, if any, free.
 - Comply with applicable technical and building regulations.
- Do not place the appliance in direct sunlight or in the vicinity of heat sources (cooker, radiator, heating devices, etc.). Heat sources may pose negative effect in terms of power consumption and lead to restrictions in operation of the appliance.
- Place the appliance so that sufficient air circulation is ensured. Leave 10 cm clearance from walls and other objects.
- The appliance may be installed only in rooms, in which ambient temperature does not exceed 30°C.

Installation and operation

- In order to avoid compressor's damage, do not tilt the appliance more than 45° when positioning or transporting it.
- If the appliance is to be relocated, follow the instructions below:
 - switch the appliance off;
 - remove the plug from the socket;
 - take out contents of the appliance;
 - use a tape to stick up all loose elements inside the appliance and the door;
 - the appliance may only be transported in upright position.

Power supply connection

- Verify if technical data of the appliance (see rating plate) correspond with the local electric power grid specification.
- Connect the appliance to a single, properly grounded mains socket with protective contact. Do not connect the appliance to a multi-socket.
- The power cord should be laid in a way preventing anyone from threading on it or tripping against it.
- Prior to first use, the appliance should be installed and left standing upright for at least 2 hours, before it is connected to power supply.
- After a power failure or when the plug is removed from the socket, do not reconnect the appliance to power supply for at least 5 minutes.

EN

5.2 Operation

Preparation of the Appliance

1. Clean the appliance, containers and bars before the first use according to instructions included in section **6 “Cleaning”**.
2. Finally, dry the appliance and accessories thoroughly.
3. insert the bars and place containers on them.
4. Tightly close the appliance lid.
5. Plug the appliance into a suitable single grounded socket.
6. Switch the appliance on, setting the ON/OFF switch at the rear wall of the appliance to “I” position.

The digital display shows current temperature inside the appliance.

7. The appliance will be cooled down to the factory pre-set temperature.

- Ice cream should be placed in the appliance only when it reaches the right temperature.
- If needed, the temperature may be altered with digital temperature control regulator buttons.

Digital temperature control / button functions



- LCD cooling indicator
- LCD defrosting indicator
- Lighting / defrosting button
- SET function button
- Digital display
- Temperature decrease button
- Temperature increase button

LCD indicators



LCD cooling indicator

This indicator is lit over cooling process; it remains off as long as the cooling temperature remains at constant level, and blinks during switch on delay.



LCD defrosting indicator



This indicator is lit over defrosting process; goes off when the defrosting process is completed, and flashes during defrost delay.

Cleaning

Setting the Selected Temperature (Selected Value)

You may set the temperature in the range of -18 °C and -25 °C.

To set or change the selected temperature value:


- Press **SET** button shortly; the set value will start to flash immediately.
- Use  or  buttons to increase or decrease temperature value.
- Use **SET** button to confirm the set temperature value.


If no button is pressed within the next 10 seconds, the digital display will show current temperature inside the appliance.

NOTE: If additional parameter settings are to be changed, contact technical service.

Manual Starting / Stopping of Defrosting Cycle

If the cooling power drops, start the defrosting manually.

Press the  button and hold it pressed for 6 seconds.

The defrosting cycle starts immediately and the  defrosting indicator is lit.

EN

Switching the Appliance Off

If the appliance is not to be used, set the ON/OFF switch to “O” position and disconnect the appliance from the power supply (pull the plug out).

6 Cleaning

6.1 Safety Instructions for Cleaning

- Before cleaning, disconnect the appliance from the power supply.
- Leave the appliance to cool down completely.
- Make sure water does not enter the appliance. Do not immerse the appliance in water or other liquids during cleaning. Do not clean the appliance with a pressurized water jet.
- Do not use any sharp or pointed, nor metal implements (knife, fork, etc.). Sharp or pointed implements may damage the appliance, and when in contact with live parts, they may cause electric shock.
- For cleaning, do not use any scouring agents that contain solvents nor corrosive cleaning agents. They may damage the surface.

6.2 Cleaning

1. Clean the appliance regularly.
2. Open the glass lid.
3. Remove the ice cream containers from the appliance and store them in the mean time in a freezing drawer or in a freezer.
4. Wash the ice cabinet and the glass lid from the inside with warm water, using soft cloth and mild washing agent.
5. Wipe the washed surfaces with a cloth moistened in clean water and dry thoroughly.
6. Wipe the appliance housing, the display surface and the glass lid from the outside with a soft cloth and damp cloth.
7. Finally, dry thoroughly all cleaned surfaces.
8. Leave the glass lid open for the appliance to dry completely.
9. Wash the bars and containers thoroughly under warm water with the use of a mild washing agent.
10. Rinse the bars and containers thoroughly in clean water and then dry thoroughly.

NOTE: The containers and ice cabinet should be cleaned regularly from inside with a food-grade cleaning disinfectant.

7 Possible Malfunctions

The table below contains descriptions of possible causes and solutions to malfunctions or errors during operation of the appliance. The works may only be performed by suitably qualified technical personnel.

When malfunction cannot be removed, contact the technical service. In such a case, provide article number, model and serial number. You will find this information on the rating plate.

Error	Possible Cause	Solution
No cooling.	The plug is not properly connected to the socket.	Remove the plug and insert it properly in the socket.
	Electric power supply safety fuse damaged.	Check the fuse, connect the appliance to another socket.
	No power supply.	Check electric power supply.
Insufficient cooling efficiency.	Direct sunlight or heat sources in immediate vicinity.	Move the appliance away from heat sources.
	Poor air circulation around the appliance.	Keep sufficient distance from walls or other objects.
	The glass lid is not entirely closed or is open for too long.	Close the glass lid and open it for as short a period as possible.
	Deformed or damaged gasket of the glass lid.	Contact the service company.
The appliance operates loudly.	The appliance is not placed on even surface.	Place the appliance on even surface.
	Appliance touches walls or other objects.	Keep sufficient distance from walls or other objects.

The following phenomena are not malfunctions:

- During normal operation, a sound of water flowing is heard. This is a sound of coolant flowing through the installation.

Water vapour condensation on glass lid in high air humidity conditions is a normal occurrence. Wipe the water vapour out with a soft, dry cloth.

8 Disposal

Electrical Appliance



Electric appliances are marked with this symbol. Electrical appliances must be disposed of and recycled in a correct and environmentally friendly manner. You must not dispose of electric appliances with household waste. Disconnect the appliance from the power supply and remove power cord from the appliance.

Electrical appliances should be returned to designated collection points.

EN

Coolant

The propellant used in the appliance is flammable. It should be utilised pursuant to national regulations in force.