

**B5000**



**137201**

Bartscher GmbH  
Franz-Kleine-Str. 28  
D-33154 Salzkotten  
Germany

Phone: +49 5258 971-0  
Fax: +49 5258 971-120  
**Service hotline:** +49 5258 971-197  
[www.bartscher.com](http://www.bartscher.com)



Version: 1.0

Date of preparation: 2024-01-09

---

## Original instruction manual

1	Safety .....	2
1.1	Explanation of Signal Words .....	2
1.2	Safety instructions.....	3
1.3	Intended Use .....	6
1.4	Unintended Use .....	6
2	General information .....	7
2.1	Liability and Warranty .....	7
2.2	Copyright Protection .....	7
2.3	Declaration of Conformity .....	7
3	Transport, Packaging and Storage .....	8
3.1	Delivery Check.....	8
3.2	Packaging .....	8
3.3	Storage .....	8
4	Technical Data.....	9
4.1	Technical Specifications .....	9
4.2	List of Components of the Appliance .....	10
4.3	Functions of the Appliance.....	12
5	Installation and operation .....	13
5.1	Installation.....	13
5.2	Operation .....	14
6	Cleaning .....	17
6.1	Safety Instructions for Cleaning .....	17
6.2	Cleaning.....	17
6.3	Maintenance .....	18
7	Disposal.....	18



**Read this instruction manual before using and keep it available at all times!**

This instruction manual contains information about installation, operation and maintenance of the appliance and constitutes an important source of information and reference guide. The knowledge of all operational and safety instructions included in this manual is a prerequisite for safe and proper handling of the appliance. Additionally, accident prevention, occupational health and safety, and legal regulations in force in the area the appliance is used apply.

Before you start using the appliance, especially before turning it on, read this instruction manual in order to avoid personal injuries and property damages. Improper use may cause damage.

This instruction manual forms an integral part of the product and must be stored in an immediate vicinity of the appliance and be available at all times. The instruction manual should be transferred together with the appliance.

## 1 Safety

This appliance has been manufactured in accordance with technical standards currently in force. However, the appliance may be a source of hazards if used improperly or contrary to its intended purpose. All persons using the appliance must consider information included in this instruction manual and observe safety instructions.

### 1.1 Explanation of Signal Words

Important safety instructions and warning information are indicated in this instruction manual with appropriate signal words. You must strictly follow the instructions, to prevent accidents, personal injuries and property damages.



**DANGER!**

The signal word **DANGER** warns against hazards that lead to severe injuries or death if the hazards are not avoided.



### **WARNING!**

The signal word **WARNING** warns against hazards that may lead to moderate or severe injuries or death if the hazards are not avoided.



### **CAUTION!**

The signal word **CAUTION** warns against hazards that may lead to light or moderate injuries if the hazards are not avoided.

### **IMPORTANT!**

The signal word **IMPORTANT** indicates possible property damages, which may occur if safety instructions are not observed.

### **NOTE!**

The symbol **NOTE** indicates subsequent information and guidelines for the user on usage of the appliance.

## 1.2 Safety instructions

### Electrical Current

- Too high a mains voltage or incorrect installation may cause electric shock.
- The appliance may be connected only if data on the rating plate correspond with the mains voltage.
- To avoid short-circuit, the appliance should be kept dry.
- If there are malfunctions during operation, disconnect the appliance from the power supply.
- Do not touch the appliance's plug with wet hands.
- Never take hold of the appliance if it has fallen into water. Immediately disconnect the appliance from the power supply.
- Any repairs or housing opening may be carried out by professionals and relevant workshops only.
- Do not transport the appliance, holding it by the power cord.
- Do not allow the power cord to come into contact with heat sources or sharp edges.
- Do not bend, pinch nor knot the power cord.

- Always completely unwind the power cord.
- Never place the appliance or other objects on the power cord.
- Always take hold of the plug to disconnect the appliance from the power supply.
- Check the power cord regularly for damage. Do not use the appliance if the power cord is damaged. If this cable is damaged, it must be replaced by customer service or a qualified electrician in order to avoid dangers.

### Flammable Materials

- Never subject the appliance to contact with high temperature sources, e.g.: oven, furnace, open flame, heat generating devices, etc.
- To avoid fire hazard, clean the appliance regularly.
- Do not cover the appliance with, e.g., aluminium foil or cloths.
- Use the appliance only with materials designated to this end and with correct temperature settings. Materials, groceries and left-overs remaining in the appliance may catch fire.
- Never use the appliance near flammable or inflammable materials, e.g.: petrol, spirit, alcohol, etc. High temperature triggers evaporation of these materials, and, as a result of contact with sources of ignition, an explosion may occur.
- In case of fire, disconnect the appliance from the power supply before attempting suitable fire-extinguishing actions.
- Never attempt to extinguish fire with water if the appliance is connected to the power supply. Following extinction of fire, ensure sufficient fresh air inflow.

### Hot Surfaces

- Surfaces of the appliance become hot during operation. Burning hazard! High temperature remains for some time after switching the appliance off.
- Do not touch any hot surfaces of the appliance. Use the provided handling elements and holders.
- You may transport and clean the appliance after it cools down entirely.
- It is prohibited to sprinkle hot surfaces with cold water or flammable liquids.

## Safety

---

### Operating personnel

- This appliance is not intended to be used by persons (including children) with limited physical, sensory or mental capabilities, nor by persons with limited experience and/or limited knowledge.
- Children should be supervised to ensure that they are not playing with or switching the appliance on.

### Supervised Usage only

- Only supervised appliance may be used.
- Always remain in an immediate vicinity of the appliance.

### Improper Use

- Unintended or prohibited use may cause damage to the appliance.
- The appliance may only be used when its technical condition is flawless and allows for safe operation.
- The appliance may only be used when all connections are executed according to rules of law in force.
- The appliance may only be used when it is clean.
- Use only original spare parts. Never attempt to repair the appliance on your own.
- Do not introduce any changes in the appliance nor modify it.

## 1.3 Intended Use

As described below, every use of the appliance for a purpose differing and/or diverging from its intended standard use, is prohibited and considered to be an unintended use.

The following is an intended use:

- Candy floss production.

## 1.4 Unintended Use

An unintended use may lead to personal injuries or property damages caused by hazardous voltage, fire or high temperature. The appliance may only be used to perform tasks described in this instruction manual.



## 2 General information

### 2.1 Liability and Warranty

All information and instructions in this instruction manual account for legal regulations in force, current level of technical engineering knowledge as well as our expertise and experience, developed over the years. If special models or additional options are ordered, or state-of-the-art technical solutions were implemented, the actual scope of delivery of the appliance may, in some circumstances, differ from descriptions and numerous drawings in this instruction manual.

The manufacturer is not liable for any damages nor faults stemming from:

- failure to observe instructions,
- unintended use,
- technical alterations introduced by the user,
- usage of unapproved spare parts.

We reserve the right to introduce technical modifications to the product, intended for improvement of the appliance and its performance.

### 2.2 Copyright Protection

This instruction manual, and texts, drawings and images included in it, as well as its other components are copyright protected. It is prohibited to reproduce this instruction manual (including its excerpts), in any form and by any means, and to use and/or transfer its content to third parties without manufacturer's written permission. Violation of the above results in obligation to pay compensation. We reserve the right to claim further damages.

EN

### 2.3 Declaration of Conformity

The appliance meets the currently applicable standards and guidelines of the European Union. We confirm the above in the EC Declaration of Conformity. We may provide relevant Declaration of Conformity upon request.

### 3 Transport, Packaging and Storage

#### 3.1 Delivery Check

Immediately upon reception, check the delivery for completeness and possible shipping damage. In the case of visible transport damage refuse to accept the appliance or accept it conditionally. Mark and note the scope of damage in shipping documents/consignment list of the shipping company and lodge a complaint. Concealed damage must be reported immediately upon its discovery, as compensation claims may only be filed within applicable time limits.

If you find that parts or accessories missing, please contact our Customer Service Department.

#### 3.2 Packaging

Do not dispose of the appliance cardboard box. It may be used to store the appliance when relocating or when shipping the appliance to our service point in the case of any damages.

The packaging and its elements are made of recyclable materials. Particularly, these are: plastic films and bags, cardboard box.

When disposing of the packaging, observe applicable domestic regulations. Recyclable packaging materials should be recycled.

#### 3.3 Storage

Leave the packaging closed until installation of the appliance; observe external indications concerning method of placing and storage. Store the packaging in the following conditions only:

- in closed rooms;
- in dry and dust-free surrounding;
- away from aggressive agents;
- in a location protected against sunlight;
- in a location protected against mechanical shocks.

In the case of extended storage (over three months), make sure you check the condition of the packaging and the parts regularly. If needed, replace the packaging with a new one.

## 4 Technical Data

### 4.1 Technical Specifications

<b>Name:</b>	<b>Candy floss machine B5000</b>
Art. No.:	<b>137201</b>
Material:	stainless steel, painted
Bowl material:	stainless steel
Inner bowl diameter, in mm:	500
Production time in sec./pcs:	30 - 60
Connected load:	1,2 kW   220-240 V   50/60 Hz
Dimensions (W x D x H), in mm:	520 x 520 x 480
Weight, in kg:	11,0

We reserve the right to implement technical modifications.

### Version / Characteristics

- Bowl:
  - detachable
  - dishwasher-safe
- Motor:
  - rocker switch
  - switched on separately
- Temperature control:
  - rocker switch
  - switched on separately
- Voltage indicator
- Fuse
- Integrated drawer: 3 partitions
- The set does not include:
  - wooden sticks
  - sugar

- The set includes:
  - spare toothed belt
  - measuring cup (12–18 g)

## 4.2 List of Components of the Appliance




Fig. 1

Delivery without wooden sticks, sugar, decoration!

## Technical Data

### Description for Fig. 1

1. Bowl
2. Rotating head
3. Rubber bumpers (4 pcs)
4. Grounding pin
5. Appliance plug-in socket
6. Control panel
7. Foot (4 pcs)
8. Housing
9. Ventilation openings
10. Hook (4 pcs)
11. Fastening clamp (4 pcs)
12. Drawer, removable
13. Measuring cup

### Control Elements / Indicator Lights




Fig. 2

14. Voltage indicator
15. Fuse
16. Heater rocker switch
17. ON/OFF switch

### Fuse

The appliance is equipped with a fuse that is activated in case of overheating of the appliance.

1. To restart the appliance, perform the following steps:
  - wait for the appliance to cool down,
  - unscrew the fuse cap (15),
  - push the pin in,
  - screw the cap back on,
  - switch the appliance on as usual.

Auxiliary equipment (not included in the delivery!)



### Protective Cover B5000

- Material: PMMA plastic
- Designed for candy floss machine B5000
- Dimensions: W 532 x D 532 x H 325 mm
- Weight: 1.2 kg

**Art no. 137202**

Fig. 3

### Characteristics

- Top hygiene standards
- Protection against external influences such as wind

EN

### Fixing / Cleaning

1. Place the protective cover over the bowl so that it is firmly attached to the bowl using the plastic hooks on its edge.
2. Clean the protective cover using warm water and a soft, lint-free cloth.

## 4.3 Functions of the Appliance

With the Candy Floss Machine B5000, candy floss can be made as light as fluff, even from small quantities of sugar. The professional and powerful appliance enables candy floss to be produced without interruption and maintains the highest level of hygiene.

## 5 Installation and operation

### 5.1 Installation



#### CAUTION!

**Incorrect installation, positioning, operation, maintenance or misuse of the appliance may lead to personal injury or property damage.**

Positioning and installation, as well as repairs may be performed by authorised technical service only and in compliance with the applicable national law.

#### NOTE!

**The manufacturer disclaims all liability and provides no warranty for damages, which may be attributed to non-observance of regulations or incorrect installation.**

### Unpacking / Positioning

EN

- Unpack the appliance, remove all external and internal packaging elements and shipment safeguards.



#### CAUTION!

#### Choking hazard!

Prevent children from accessing package materials, for instance: plastic bags and EPS.

- If the appliance is covered with a protective film, remove it. Remove the film slowly, so no glue residues are left. Remove any glue residues with the use of a suitable solvent.
- Be careful not to damage the rating plate and warning labels fixed on the appliance.
- **Never** place the appliance in humid or wet environment.
- Place the appliance in a way making the connections easily accessible, so that they may be quickly disconnected if such a need arises.
- The appliance should be placed on surfaces that are:
  - even, with sufficient bearing capacity, resistant to water, dry and resistant to high temperatures;

- sufficiently large, and thus enabling usage of the appliance with no problems;
  - easily accessible;
  - well ventilated.
- Maintain sufficient clearance from table edges. The appliance might turn over and fall down.
  - Leave at least 10 cm clearance from flammable walls and items.

### Power supply connection

- Verify if technical data of the appliance (see rating plate) correspond with the local electric power grid specification.
- Connect the appliance to a single, properly grounded mains socket with protective contact. Do not connect the appliance to a multi-socket.
- The power cord should be laid in a way preventing anyone from threading on it or tripping against it.

## 5.2 Operation



### WARNING

#### Hot surface!

#### The rotating head and bowl get very hot during operation.

Never touch the rotating head nor bowl during operation.

Never touch the hot caramelised sugar in the bowl with your hands during operation or immediately after operation.



### Appliance Preparation

1. Before starting-up, clean the appliance and its equipment inside and outside observing instructions in section '**Cleaning**'.
2. Dry all cleaned elements and surfaces thoroughly.
3. Refit the removed parts back in the appliance:
  - place the bowl on rubber bumpers on the appliance housing,
  - fix the bowl on the hooks in the bottom using the clamps on both sides,
  - attach the drawer.

### Preparing Candy Floss Ingredients

With this candy floss machine you can make candy floss very easily. The appliance makes sweet candy floss from air and sugar.

To produce candy floss, few ingredients are required:

- sugar, preferably refined,
- wooden sticks with a rough, angular surface so that the candy floss sticks well (candy floss can slide off smooth wooden sticks),
- various food colourings and flavourings, as desired.

### Appliance Start-up

1. First, connect the plug of the power cord to the plug-in socket of the appliance, located on the right side of the appliance.
2. Plug the power cord plug into a suitable single socket.
3. Switch the appliance on with the ON/OFF rocker switch (set to '**I**' position).
4. Leave the appliance to operate for approx. 1–2 minutes.
5. Check whether the appliance runs evenly or not.
6. Switch the heater rocker switch to ON '**I**' position.
7. For initial heating, leave the appliance to operate for approx. 4–5 minutes.
8. Switch the appliance off and wait for the rotating head to stop.

### Candy Floss Production



Fig. 4



Fig. 5

1. Fill the supplied measuring cup with sugar.
2. Carefully pour the sugar into the centre of the rotating head.
3. Switch the appliance on again and hold the prepared wooden stick.

After a few minutes, the appliance starts to spin the first sugar flosses.

4. First hold the stick vertically and guide it around in the bowl.
5. In doing so, rotate the stick in your fingers to wind the candy floss.
6. Once some candy floss has collected on the stick, hold it horizontally.
7. Continue to move the stick to collect the candy floss over the bowl.

8. If no more sugar flosses are forming, finish the process.
9. Serve the finished candy floss on a wooden stick.
10. Prepare the desired amount of candy floss. Repeat the steps described above.
11. Following use, clean the appliance thoroughly, observing indications in section '**Cleaning**'.

### Switching the Appliance OFF

1. If the appliance is no longer to be used, switch it off by switching the heater rocker switch and the ON/OFF rocker switch to the 'O' position.
2. Disconnect the appliance from mains power supply (pull the plug out) and then the plug of the power cord from the appliance plug-in socket.

## 6 Cleaning

### 6.1 Safety Instructions for Cleaning

- Before cleaning, disconnect the appliance from the power supply.
- Leave the appliance to cool down completely.
- Make sure water does not enter the appliance. Do not immerse the appliance in water or other liquids during cleaning. Do not clean the appliance with a pressurized water jet.
- Do not use any sharp or pointed, nor metal implements (knife, fork, etc.). Sharp or pointed implements may damage the appliance, and when in contact with live parts, they may cause electric shock.
- For cleaning, do not use any scouring agents that contain solvents nor corrosive cleaning agents. They may damage the surface.

### 6.2 Cleaning

#### **ATTENTION!**

**The rotating head and bowl should not be cleaned with any cleaning agents. If residues of these cleaners are left on the surface, ignition and soiling may occur at start-up.**

1. Clean the rotating head and bowl immediately after preparing candy floss:
  - do not switch the appliance off immediately,
  - pour some water over the rotating head when it is running,
  - leave the appliance operating for a while,
  - switch the appliance off with the ON/OFF rocker switch (set to 'O'),
  - wipe the rotating head with a soft cloth,
  - wipe the bowl to remove any sugar residues.
2. Release the bowl fastening clamps and remove the bowl from the appliance.
3. Clean the bowl using warm water and a soft, lint-free cloth.

4. Wipe the appliance housing and drawer with a soft, damp cloth.
5. Dry all the cleaned elements and surfaces completely with a soft cloth.
6. Reattach the removed parts to the appliance.

### 6.3 Maintenance

- If the toothed belt becomes loose after a long period of use, have it replaced by an authorised service centre. A spare toothed belt is included in the scope of delivery.

## 7 Disposal

### Electrical Appliance



Electric appliances are marked with this symbol. Electrical appliances must be disposed of and recycled in a correct and environmentally friendly manner. You must not dispose of electric appliances with household waste. Disconnect the appliance from the power supply and remove power cord from the appliance.

Electrical appliances should be returned to designated collection points.