

1160



117712

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

Phone: +49 5258 971-0
Fax: +49 5258 971-120
Service hotline: +49 5258 971-197
www.bartscher.com



Version: **1.0**

Date of preparation: **2023-01-09**

Original instruction manual

1	Safety	2
1.1	Explanation of Signal Words	2
1.2	Safety instructions.....	3
1.3	Intended Use	6
1.4	Unintended Use	6
2	General information	7
2.1	Liability and Warranty	7
2.2	Copyright Protection	7
2.3	Declaration of Conformity	7
3	Transport, Packaging and Storage	8
3.1	Delivery Check.....	8
3.2	Packaging	8
3.3	Storage	8
4	Technical Data.....	9
4.1	Technical Specifications	9
4.2	Functions of the Appliance.....	10
4.3	List of Components of the Appliance	11
5	Installation and operation	12
5.1	Installation.....	12
5.2	Operation	13
6	Cleaning and Maintenance	20
6.1	Safety Instructions for Cleaning	20
6.2	Cleaning.....	20
7	Possible Malfunctions.....	21
8	Disposal.....	22



Read this instruction manual before using and keep it available at all times!

This instruction manual contains information about installation, operation and maintenance of the appliance and constitutes an important source of information and reference guide. The knowledge of all operational and safety instructions included in this manual is a prerequisite for safe and proper handling of the appliance. Additionally, accident prevention, occupational health and safety, and legal regulations in force in the area the appliance is used apply.

Before you start using the appliance, especially before turning it on, read this instruction manual in order to avoid personal injuries and property damages. Improper use may cause damage.

This instruction manual forms an integral part of the product and must be stored in an immediate vicinity of the appliance and be available at all times. The instruction manual should be transferred together with the appliance.

1 Safety

This appliance has been manufactured in accordance with technical standards currently in force. However, the appliance may be a source of hazards if used improperly or contrary to its intended purpose. All persons using the appliance must consider information included in this instruction manual and observe safety instructions.

1.1 Explanation of Signal Words

Important safety instructions and warning information are indicated in this instruction manual with appropriate signal words. You must strictly follow the instructions, to prevent accidents, personal injuries and property damages.



DANGER!

The signal word **DANGER** warns against hazards that lead to severe injuries or death if the hazards are not avoided.



WARNING!

The signal word **WARNING** warns against hazards that may lead to moderate or severe injuries or death if the hazards are not avoided.



CAUTION!

The signal word **CAUTION** warns against hazards that may lead to light or moderate injuries if the hazards are not avoided.

IMPORTANT!

The signal word **IMPORTANT** indicates possible property damages, which may occur if safety instructions are not observed.

NOTE!

The symbol **NOTE** indicates subsequent information and guidelines for the user on usage of the appliance.

1.2 Safety instructions

Electrical Current

- Too high a mains voltage or incorrect installation may cause electric shock.
- The appliance may be connected only if data on the rating plate correspond with the mains voltage.
- To avoid short-circuit, the appliance should be kept dry.
- If there are malfunctions during operation, disconnect the appliance from the power supply.
- Do not touch the appliance's plug with wet hands.
- Never take hold of the appliance if it has fallen into water. Immediately disconnect the appliance from the power supply.
- Any repairs or housing opening may be carried out by professionals and relevant workshops only.
- Do not transport the appliance, holding it by the power cord.
- Do not allow the power cord to come into contact with heat sources or sharp edges.
- Do not bend, pinch nor knot the power cord.

- Always completely unwind the power cord.
- Never place the appliance or other objects on the power cord.
- Always take hold of the plug to disconnect the appliance from the power supply.
- Check the power cord regularly for damage. Do not use the appliance if the power cord is damaged. If this cable is damaged, it must be replaced by customer service or a qualified electrician in order to avoid dangers.

Flammable Materials

- Never subject the appliance to contact with high temperature sources, e.g.: oven, furnace, open flame, heat generating devices, etc.
- To avoid fire hazard, clean the appliance regularly.
- Do not cover the appliance with, e.g., aluminium foil or cloths.
- Use the appliance only with materials designated to this end and with correct temperature settings. Materials, groceries and left-overs remaining in the appliance may catch fire.
- Never use the appliance near flammable or inflammable materials, e.g.: petrol, spirit, alcohol, etc. High temperature triggers evaporation of these materials, and, as a result of contact with sources of ignition, an explosion may occur.
- In case of fire, disconnect the appliance from the power supply before attempting suitable fire-extinguishing actions.
- Never attempt to extinguish fire with water if the appliance is connected to the power supply. Following extinction of fire, ensure sufficient fresh air inflow.

Safety

Hot Surfaces

- Surfaces of the appliance become hot during operation. Burning hazard! High temperature remains for some time after switching the appliance off.
- Do not touch any hot surfaces of the appliance. Use the provided handling elements and holders.
- You may transport and clean the appliance after it cools down entirely.
- It is prohibited to sprinkle hot surfaces with cold water or flammable liquids.

Operating Personnel

- The appliance may only be operated by qualified personnel and trained specialist personnel.
- This appliance may not be operated by persons (including children) with limited physical, sensory or mental capabilities, nor by persons with limited experience and/or limited knowledge.
- Children should be supervised to ensure that they are not playing with or switching on the appliance.

Supervised Usage only

- Only supervised appliance may be used.
- Always remain in an immediate vicinity of the appliance.

EN

Improper Use

- Unintended or prohibited use may cause damage to the appliance.
- The appliance may only be used when its technical condition is flawless and allows for safe operation.
- The appliance may only be used when all connections are executed according to rules of law in force.
- The appliance may only be used when it is clean.
- Use only original spare parts. Never attempt to repair the appliance on your own.
- Do not introduce any changes in the appliance nor modify it.

1.3 Intended Use

As described below, every use of the appliance for a purpose differing and/or diverging from its intended standard use, is prohibited and considered to be an unintended use.

The following is an intended use:

- Smoking of suitable foods in a combi-steamer.

1.4 Unintended Use

An unintended use may lead to personal injuries or property damages caused by hazardous voltage, fire or high temperature. The appliance may only be used to perform tasks described in this instruction manual.

The following is an unintended use:

- Smoking of unsuitable food products.

2 General information

2.1 Liability and Warranty

All information and instructions in this instruction manual account for legal regulations in force, current level of technical engineering knowledge as well as our expertise and experience, developed over the years. If special models or additional options are ordered, or state-of-the-art technical solutions were implemented, the actual scope of delivery of the appliance may, in some circumstances, differ from descriptions and numerous drawings in this instruction manual.

The manufacturer is not liable for any damages nor faults stemming from:

- failure to observe instructions,
- unintended use,
- technical alterations introduced by the user,
- usage of unapproved spare parts.

We reserve the right to introduce technical modifications to the product, intended for improvement of the appliance and its performance.

2.2 Copyright Protection

This instruction manual, and texts, drawings and images included in it, as well as its other components are copyright protected. It is prohibited to reproduce this instruction manual (including its excerpts), in any form and by any means, and to use and/or transfer its content to third parties without manufacturer's written permission. Violation of the above results in obligation to pay compensation. We reserve the right to claim further damages.

EN

2.3 Declaration of Conformity

The appliance meets the currently applicable standards and guidelines of the European Union. We confirm the above in the EC Declaration of Conformity. We may provide relevant Declaration of Conformity upon request.

3 Transport, Packaging and Storage

3.1 Delivery Check

Immediately upon reception, check the delivery for completeness and possible shipping damage. In the case of visible transport damage refuse to accept the appliance or accept it conditionally. Mark and note the scope of damage in shipping documents/consignment list of the shipping company and lodge a complaint. Concealed damage must be reported immediately upon its discovery, as compensation claims may only be filed within applicable time limits.

If you find that parts or accessories missing, please contact our Customer Service Department.

3.2 Packaging

Do not dispose of the appliance cardboard box. It may be used to store the appliance when relocating or when shipping the appliance to our service point in the case of any damages.

The packaging and its elements are made of recyclable materials. Particularly, these are: plastic films and bags, cardboard box.

When disposing of the packaging, observe applicable domestic regulations. Recyclable packaging materials should be recycled.

3.3 Storage

Leave the packaging closed until installation of the appliance; observe external indications concerning method of placing and storage. Store the packaging in the following conditions only:

- in closed rooms;
- in dry and dust-free surrounding;
- away from aggressive agents;
- in a location protected against sunlight;
- in a location protected against mechanical shocks.

In the case of extended storage (over three months), make sure you check the condition of the packaging and the parts regularly. If needed, replace the packaging with a new one.

4 Technical Data

4.1 Technical Specifications

Name:	Smoker-Box 1160
Art. No.:	117712
Material:	stainless steel
Version:	with heating coil
Volume, in litres	1,16
Smoker-Box dimensions (W x D), in mm:	125 x 470 x 75
Max. smoking temperature, in °C:	200
Connected load:	0,2 kW 230 V 50/60 Hz
Dimensions (W x D x H), in mm:	555 x 365 x 180
Weight, in kg:	6,5

We reserve the right to implement technical modifications.

EN

Version / Characteristics

- Designed for: combi-steamers
- Consists of:
 - mains adapter
 - Smoker-Box
- Suitable fuel: standard smoking materials
- ON/OFF switch
- Indicator light:
 - ready for operation
 - heating-up


The Smoker-Box can be combined with the following appliances:

116626	116728	116731
117725	117727	117730
117650	117761	117762
117763	117741	117781
117731	117672	117764
117765	117766	117262
117263	117264	117265

4.2 Functions of the Appliance

Smoking aromas give a unique flavour to meat, fish and also vegetables. With the Smoker-Box, dishes get this amazing flavour right from the cooking stage. The simple handling speaks for itself: just connect the Smoker-Box to the power supply and you are ready to start smoking in a combi-steamer.

4.3 List of Components of the Appliance



EN

- | | |
|--------------------------------|-------------------------------|
| 1. Mains adapter | 2. ON/OFF switch |
| 3. Fuse | 4. Cord connection |
| 5. Plug connection | 6. Orange LED indicator light |
| 7. Green LED indicator light | 8. Smoker-Box lid |
| 9. Ventilation openings | 10. Heating coil |
| 11. Smoker-Box housing | 12. Smoker-Box handle |
| 13. Connection cable | 14. Plug |
| 15. Power cord with mains plug | |

Fig. 1

5 Installation and operation



CAUTION!

Incorrect installation, positioning, operation, maintenance or misuse of the appliance may lead to personal injury or property damage.

Positioning and installation, as well as repairs may be performed by authorised technical service only and in compliance with the applicable national law.

NOTE!

The manufacturer disclaims all liability and provides no warranty for damages, which may be attributed to non-observance of regulations or incorrect installation.

5.1 Installation

EN

Unpacking / Positioning

- Unpack the appliance, remove all external and internal packaging elements and shipment safeguards.



CAUTION!

Choking hazard!

Prevent children from accessing package materials, for instance: plastic bags and EPS.

- If the appliance is covered with a protective film, remove it. Remove the film slowly, so no glue residues are left. Remove any glue residues with the use of a suitable solvent.
- Be careful not to damage the rating plate and warning labels fixed on the appliance.
- **Never** place the appliance in humid or wet environment.
- Place the appliance in a way making the connections easily accessible, so that they may be quickly disconnected if such a need arises.
- The appliance should be placed on surfaces that are:
 - even, with sufficient bearing capacity, resistant to water, dry and resistant to high temperatures;

Installation and operation

- sufficiently large, and thus enabling usage of the appliance with no problems;
 - easily accessible;
 - well ventilated.
- Maintain sufficient clearance from table edges. The appliance might turn over and fall down.

Power supply connection

- Verify if technical data of the appliance (see rating plate) correspond with the local electric power grid specification.
- Connect the appliance to a single, properly grounded mains socket with protective contact. Do not connect the appliance to a multi-socket.
- The power cord should be laid in a way preventing anyone from threading on it or tripping against it.

5.2 Operation



WARNING

EN

Risk of burning!

The Smoker-Box becomes very hot during operation and remains hot for some time after removal and switching off.

Do not touch the appliance during operation nor immediately after switching it off.

Be very careful when removing the Smoker-Box. Use heat-resistant gloves.

Fire hazard!

Wood chips or leftover pellets can be very hot.

Make sure that wood chips or pellets do not come into contact with flammable or combustible materials or liquids.

Preparation of the Appliance

1. Before starting up, clean the appliance and equipment according to instructions in section '**Cleaning**'.
2. Dry the appliance.

Filling the Smoker-Box



Fig. 2



Fig. 3

1. Open the Smoker-Box by lifting the lid upwards.
2. Fill the Smoker-Box with sufficient wood chips.

WARNING!

Use natural, unprocessed products only, such as wood chips or suitable pellets that are not harmful to health.

Connecting Mains Adapter to Smoker-Box




Fig. 4

1. Connect the Smoker-Box to the mains adapter using the connection cable (13) and plug (14) (Fig. 4).
2. Plug the mains adapter into a suitable single socket.

When the mains adapter is plugged in, the green LED indicator light (7) will illuminate.

Placing Smoker-Box in Combi-Steamer

The Smoker-Box is compatible with a number of appliances as indicated in section 'Version / Characteristics'.

NOTE!

We recommend that you use the Smoker-Box only in models with the automatic cleaning function.



Fig. 5

1. Place the Smoker-Box inside the combi-steamer in the following order:
 - place the Smoker-Box on a baking tray,
 - place the baking tray with the Smoker-Box on the top shelf to avoid cooking liquids dripping down onto the Smoker-Box,
 - route the connection cable between the combi-steamer seal and the inner door glass of the combi-steamer.

ATTENTION!

The connection cable can become deformed or damaged if it is not placed correctly.

Route the connection cable between the inner door glass of the combi-steamer and the combi-steamer door seal, away from the condensation drip tray in the combi-steamer door.

In case the connection cable is damaged, do not use the combi-steamer and contact the service company.

Setting Combi-Steamer for Smoking Cycle

Introduce the following combi-steamer settings for the smoking mode:

Preparation type: Circulating air

Temperature: max. 200°C

Fume extractor: closed

Fan speed: max. 3

If the temperature is set below 90°C, the fan speed must be set between 1 and 2.

NOTE!

Follow the instructions in the combi-steamer user manual to set the smoking mode.

ATTENTION!

Too high temperatures in the combi-steamer may lead to damage of the connection pipe.

During smoking cycle, never set the temperature in the combi-steamer higher than 200°C.

Appliance Start-Up

1. To switch the Smoker-Box on, press the ON/OFF switch (2, Fig. 4).

The orange LED indicator light (3) lights up and the Smoker-Box is heated.

After approx. 10–15 minutes, depending on the wood used, smoke starts to be generated.

End of Smoking Cycle

1. When the smoking cycle is complete, switch the Smoker-Box off using the mains adapter.
2. Carefully remove the Smoker-Box from the combi-steamer using heat-resistant gloves.
3. Disconnect the mains adapter from the mains supply and the Smoker-Box from the mains supply.
4. When the Smoker-Box has cooled down, empty it.

Recommendations for Smoking

Depending on the food to be smoked, different types of wood are used. Both dry wood and wood that has been soaked in water for a short time (10–20 minutes) can be used.

Type of wood	Properties	Recommended food
ALDER	Very delicate, slightly sweet	Fish, pork, chicken, white poultry meat
ALMOND TREE	Sweet	All types of meat
APPLE TREE	Light, specific aftertaste	Fish and red meat
ASH	Aftertaste similar to maple	Pork and poultry
BEECH	Considered the best wood for smoking	Poultry, pork and beef
CHERRY TREE	Acidic, strongly smoky. Juicy and fruity	Poultry, pork and beef
GRAPEVINE WOOD	Acidic, juicy and fruity	Poultry, red meat, lamb
BLACK WALNUT	Sweet and strong, with a bacon aftertaste	Pork, ham and beef
LILAC	Very light, slightly floral aftertaste	Shellfish, seafood and lamb
MAPLE	Delicate and slightly sweet	Pork, poultry, small game and cheeses
LEGUME	Strong aftertaste	Beef, fish, poultry and game
MULBERRY	Sweet aroma, reminiscent of apple	Shellfish, poultry and lamb

Type of wood	Properties	Recommended food
OAK	Strong aftertaste	Pork, red meat, fish and coarse game
WHISKY OAK	Whisky aftertaste	Pork, red meat, fish and coarse game
ORANGE TREE	Light aftertaste	Beef, pork, fish and poultry
PEAR TREE	Very light	Poultry and pork
PECAN	Sweet and light	Poultry, beef, pork and cheese
PLUM TREE	Delicate aroma.	Optimal for white and pink meat
COMMON WALNUT	Heavy smoke, use with other woods	Pink meat and game

Hot and Cold Smoking

You can smoke both in cold and hot mode, depending on the product and the desired effect. Hot smoking means: smoking and heat treatment. For this purpose, the combi-steamer can be set to heat treatment in Delta-T mode or to a constant temperature.

For cold smoking, such as smoked salmon, it is advisable to place a baking tray with ice on the lowest shelf of the combi-steamer to keep the temperature down.

6 Cleaning and Maintenance

6.1 Safety Instructions for Cleaning

- Before cleaning, disconnect the appliance from the power supply.
- Leave the appliance to cool down completely.
- Make sure water does not enter the appliance. Do not immerse the appliance in water or other liquids during cleaning. Do not clean the appliance with a pressurized water jet.
- Do not use any sharp or pointed, nor metal implements (knife, fork, etc.). Sharp or pointed implements may damage the appliance, and when in contact with live parts, they may cause electric shock.
- For cleaning, do not use any scouring agents that contain solvents nor corrosive cleaning agents. They may damage the surface.

6.2 Cleaning

1. For hygienic reasons and to avoid malfunctions, clean the appliance regularly at the end of the working day.
2. Clean the Smoker-Box with warm water, mild washing agent and soft cloth or sponge.

ATTENTION!

Never use steel wool, steel brushes nor steel spatulas to clean the Smoker-Box so as not to damage the surface.

3. Wipe the outside surfaces of the Smoker-Box and the mains adapter, as well as the connection cable, with a slightly damp cloth only.
4. Dry all cleaned surfaces with a soft cloth.

7 Possible Malfunctions


The table below contains descriptions of possible causes and solutions to malfunctions or errors during operation of the appliance. When malfunction cannot be removed, contact the technical service.

In such a case, provide article number, model name and serial number. These data may be found in the rating plate.

Problem	Possible Cause	Solution
Smoker-Box does not heat up, although the orange LED indicator light on the mains adapter is on.	Plug is not inserted	Insert the plug into a suitable mains socket
	The fuse at the back of the mains adapter has blown	Disconnect the connector and check the fuse (3, Fig. 1) at the back of the mains adapter; if necessary, reset it with a screwdriver If the problem persists, contact the service company

8 Disposal

Electrical Appliance

	<p>Electric appliances are marked with this symbol. Electrical appliances must be disposed of and recycled in a correct and environmentally friendly manner. You must not dispose of electric appliances with household waste. Disconnect the appliance from the power supply and remove power cord from the appliance.</p>
---	---

Electrical appliances should be returned to designated collection points.