

0,75L



190139

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

Phone: +49 5258 971-0
Fax: +49 5258 971-120
Service hotline: +49 5258 971-197
www.bartscher.com

Version: 1.0

Date of preparation: 2022-05-02

Original instruction manual

Technical Specifications

Name:	Glass carafe 0,75L
Item No.:	190139
Material:	glass, stainless steel, rubber
Useful content, in litres:	0,75
Dimensions (W x D x H), in mm:	100 x 100 x 295
Weight, in kg:	0,58

We reserve the right to implement technical modifications!

Version / Characteristics

- Lid model:
 - With spout
 - Automatic cover flap
 - Integrated screen
 - Detachable
- Glass carafe suitable for dishwashers
- Lid not suitable for dishwasher



EN

Abb. 1

Intended Use

The 750 ml glass carafe is designed for serving suitable beverages.

Care and Cleaning Instructions

ATTENTION!

Never use caustic nor harsh cleaning agents, which may damage the surface of the carafe.

Never wash the lid of the carafe in a dishwasher.

1. Prior to first use and after each subsequent use clean the carafe and lid thoroughly, using warm water and mild cleaning agent.
2. To end with, rinse the carafe and lid a few times with fresh water.
3. Use a soft, lint-free cloth to dry the external surface of the carafe and lid.
4. Leave the carafe open after cleaning to let it dry well.
5. To remove stubborn deposits, pour into an empty carafe half a cup of apple vinegar, add a pack of baking powder or baking soda and top up with hot water. Mix the cleaning solution and leave for approx. 15 - 20 minutes for it to take an effect.
6. Pour out the cleaning solution and rinse the carafe a few times with fresh water.