

**900-400 | 900-800 | 900-1200**



**295200 - 295201 - 295203**

Bartscher GmbH  
Franz-Kleine-Str. 28  
D-33154 Salzkotten  
Germany

Phone: +49 5258 971-0  
Fax: +49 5258 971-120  
**Service hotline:** +49 5258 971-197  
[www.bartscher.com](http://www.bartscher.com)

Version: 1.0

Date of preparation: 2024-02-13

## **Original Installation Instructions**

## Technical data

|  |                             |
|--|-----------------------------|
| <b>Name:</b>                                     | <b>Kitchen rail 900-400</b> |
| Art. No.:  | <b>295200</b>               |
| Material:  | stainless steel             |
| Designed for:                                    | Series 900                  |
| Device width, in mm:                             | 400                         |
| Max. load-bearing capacity, in kg:               | 15                          |
| Depth of the surface for placing objects, in mm: | 60                          |
| Dimensions (W x D x H), in mm:                   | 390 x 95 x 40               |
| Weight, in kg:                                   | 0,81                        |

As an accessory, the kitchen rail 295200 fits the following appliances:

|         |                   |         |                     |
|---------|-------------------|---------|---------------------|
| 296411  | Electric kitchen  | 296630  | Deep fryer          |
| 296318  | Induction kitchen | 2959961 | Deep fryer          |
| 296303  | Bain-marie        | 296311  | Pasta brewer        |
| 296105  | Work element      | 2953031 | Pasta brewer        |
| 296507  | Grill plate       | 2859251 | Deep fryer          |
| 2955041 | Grill plate       | 2954521 | Volcanic lava grill |

|  |                             |
|--|-----------------------------|
| <b>Name:</b>                                     | <b>Kitchen rail 900-800</b> |
| Art. No.:  | <b>295201</b>               |
| Material:  | stainless steel             |
| Designed for:                                    | Series 900                  |
| Device width, in mm:                             | 800                         |
| Max. load-bearing capacity, in kg:               | 15                          |
| Depth of the surface for placing objects, in mm: | 60                          |
| Dimensions (W x D x H), in mm:                   | 790 x 95 x 40               |
| Weight, in kg:                                   | 1,5                         |

As an accessory, the kitchen rail 295201 fits the following appliances:

|         |                   |         |                     |
|---------|-------------------|---------|---------------------|
| 2951131 | Gas stove         | 296106  | Work element        |
| 2952271 | Gas stove         | 296426  | Multi pan           |
| 2952171 | Gas stove         | 296510  | Grill plate         |
| 296421  | Electric kitchen  | 296511  | Grill plate         |
| 296431  | Electric kitchen  | 2955081 | Grill plate         |
| 296215  | Electric kitchen  | 2955061 | Grill plate         |
| 296325  | Electric kitchen  | 296970  | Deep fryer          |
| 296319  | Induction kitchen | 2959521 | Deep fryer          |
| 296304  | Bain-marie        | 2954631 | Volcanic lava grill |

|  |                              |
|--|------------------------------|
| <b>Name:</b>                                     | <b>Kitchen rail 900-1200</b> |
| Art. No.:  | <b>295203</b>                |
| Material:  | stainless steel              |
| Designed for:                                    | Series 900                   |
| Device width, in mm:                             | 1200                         |
| Max. load-bearing capacity, in kg:               | 15                           |
| Depth of the surface for placing objects, in mm: | 60                           |
| Dimensions (W x D x H), in mm:                   | 1190 x 95 x 40               |
| Weight, in kg:                                   | 2,1                          |

We reserve the right to implement technical modifications.

As an accessory, the kitchen rail 295203 fits the following appliances:

|         |                  |
|---------|------------------|
| 2951121 | Gas stove        |
| 2952181 | Gas stove        |
| 2952291 | Gas stove        |
| 296217  | Electric kitchen |

EN

## Intended Use

Equipping the 900 series appliances with a kitchen rail is not only a stylish finishing touch, but also offers optimization in terms of safety and functionality. Increasing distance from an appliance effectively reduces the risk of burns from contact with high-temperature zones. In addition, the sturdy design ensures that pots, pans and plates can be stored comfortably.

## Scope of Delivery / Part Name

1. Unpack the kitchen rail and remove all packing materials pursuant to environmental regulations.
2. Check completeness of delivery according to the list below:




Fig. 1

EN

1. Rail-shelf
2. Template for drilling holes
3. Nut screws (4 pcs)
4. Hexagonal head bolts (4 pcs)

### NOTE!

**Tools needed: Crimping pliers and a wrench**

## Assembly



Fig. 2



Fig. 3



Fig. 4

1. To install the kitchen rail, drill the necessary holes in the device.
2. To this end, apply the included template for drilling holes from the outside, as far as it goes, to the edges of an appliance.
3. Now, drill the holes (2 x left and 2 x right) at the locations indicated by the template for drilling holes.

4. Position the rail so that the holes in it match the drilled holes.
5. Using crimping pliers, place the nut screws in the drilled holes.
6. Screw the rail to the housing with hexagonal head bolts, tightening them with a wrench.

The kitchen rail is properly installed when it is flushed with the top edge of the housing.

## Cleaning

### ***ATTENTION!***

**For cleaning, do not use any scouring agents containing solvents nor corrosive cleaning agents. They may damage the surface.**

1. Clean the kitchen rail regularly with warm water and a soft, damp cloth. Use a mild cleaning agent when required.
2. Dry the kitchen rail with a soft cloth.