



HL = Kontrollampe, Heizkörper / heating indicator light
 S = Schalter/power switch

EH = Heizkörper/heating element
 ST = Thermostat/Thermostat