



860.001

Bedienungsanleitung

Wandascher, silber

Seite 3 bis 4

D/A/CH

Instruction manual

Wall-mounted ashtray, silver

from page 5 to 6

GB/UK

Mode d'emploi


Cendrier mural, argenté

de page 7 à page 8

F/B/CH

PRODUCT DESCRIPTION:

Description:	● Wall-mounted ashtray, silver
Article Number:	● 860.001
Style:	● Stainless steel casing
Dimensions:	● W 280 x D 140 x H 373 mm
Weight:	● 2,75 kg
Accessories:	● 4 Crosshead Screws 3,9 x 25 mm, 4 raw plugs 6 mm

MOUNTING INSTRUCTIONS:

- Open the wall ashtray and take out the ash compartments.
- Drill 4 holes in the required position with a 6mm stone drill.
- Place the 4 raw plugs in the holes.
- Affix the wall ashtray using the screws provided.
- Position the ash compartment inside the wall ashtray.
- Lock the wall ashtray back into position.

EMPTYING AND CLEANING

- Remove contents from the ash compartment regularly.
- To empty the ash compartment, open the wall ashtray and pull out the ash compartment.
- Having emptied the contents, place the ash compartment back into the wall ashtray and lock back into position.

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120