



- S1    Hauptschalter/main switch
- TR    Regulierungsthermostat/adjustment thermostat
- TS    Sicherheitsthermostat/safety thermostat
- R1    Heizwiderstand/resistance
- L1    Kontrollleuchte/indicator light