

5400 2E-K



700356

Technical specification


Name	Buffet cabinet 5400 2E-K
Code-No.:	700356
Material:	Glass, stainless steel
Colour:	silver
Model:	<ul style="list-style-type: none"> ▪ Number of levels: 2 ▪ Size of surface: <ul style="list-style-type: none"> - Top: W 540 x D 320 x H 120 mm - Below: W 540 x D 320 x H 150 mm ▪ Door cut-out size: <ul style="list-style-type: none"> - Below: W 540 x H 150 mm - Top: W 540 x H 120 mm ▪ Properties: <ul style="list-style-type: none"> - Insert shelf can be removed - Glass door with lock ▪ Can be taken out from both sides
Dimensions:	W 550 x D 375 x H 370 mm
Weight:	11.55 kg

We reserve the right to implement the technical modifications!

Use as intended

The buffet cabinet is intended for presentation of food that is not susceptible to temperature, such as biscuits, dry cakes, chocolates, filled buns and sandwiches. Products displayed on 2 levels, which saves room.


Overview of parts



- 1 Left side glass
- 2 Top glass
- 3 Right side glass
- 4 Top rear glass door
- 5 Below rear glass door
- 6 Feet (4x)
- 7 Shelves
- 8 Base unit
- 9 Glass door handle (4x)
- 10 Below front glass door
- 11 Top front glass door

User instructions

- Unpack the buffet cabinet and remove the packing material according to the environmental regulations.
- The buffet cabinet should be thoroughly cleaned before the first use. Follow the instructions in section 6 “**Cleaning instructions**”.
- Place the buffet cabinet on an even surface.
- When placing the buffet cabinet, make sure there is enough space from both sides to open the glass doors.
- Do not locate the buffet cabinet in the place exposed to the direct sunlight.
- Do not store perishable products in the buffet cabinet.
- The base of the buffet cabinet is permanently fixed, glass shelves can be removed. Both surfaces can be used to present relevant food products.
- Prepare appropriate food products and place them on the base / shelf area.



- To remove the presented food products, open relevant glass door from the front or rear.

- The glass door can be locked in the open position, which is served by two locks at each glass door.
- Soft buffers protect the door against strong impact if it suddenly drops down.



Cleaning instructions

- Remove the shelf.
- Clean the shelf and interior and exterior of the buffet cabinet with a soft, wet, lint-free cloth or sponge. Finally, dry all cleaned surfaces with a soft, lint-free cloth.
- In case of strong contamination, use a mild cleaning agent.
- **Never** use harsh or coarse cleaning agent which may scratch the surface of the buffet cabinet.

Bartscher GmbH
Franz-Kleine-Str. 28
33154 Salzkotten
Germany

phone: +49 5258 971-0
fax: +49 5258 971-120
Service-Hotline: +49 5258 971-197
www.bartscher.com