



S1/S2
EH1/EH2/EH3/EH4
ST1/ST2
HL1/HL2

Schalter/switch
Heizkörper/Heating element
Thermostat
Kontrolllampe/indicator light