

# **TSA300V**



300055

Bartscher GmbH Phone: +49 5258 971-0 Franz-Kleine-Str. 28 Fax: +49 5258 971-120

D-33154 Salzkotten Service hotline: +49 5258 971-197

Germany www.bartscher.com

Version: 1.0

Date of preparation: 2023-03-03

# Original instruction manual



#### **Technical Data**

| Name:  | Serving trolley TSA300V |  |
|--|-------------------------|--|
| Art. No.:                                    | 300055                  |  |
| Material:                                    | plastic, aluminium      |  |
| Number of shelves:                           | 3                       |  |
| Shelf dimensions (W x D), in mm:             | 785 x 485               |  |
| Clearance between shelves, in mm:            | 295                     |  |
| Max. load-bearing capacity per shelf, in kg: | 40                      |  |
| Max. total load-bearing capacity, in kg:     | 120                     |  |
| Number of swivel casters:                    | 4                       |  |
| Locking swivel casters:                      | 2                       |  |
| Diameter of swivel casters, in mm:           | 100                     |  |
| Number of caster dampers:                    | 4                       |  |
| Material of caster dampers:                  | plastic                 |  |
| Dimensions (W x D x H), in mm:               | 1000 x 495 x 920        |  |
| Weight, in kg:                               | 15,4                    |  |

We reserve the right to implement technical modifications.

300055 3 / 10



#### **Version / Characteristics**

- · Colour: black
- Delivery form: self-assembly set, simple assembly
- Purpose:
  - transportation
  - serving
  - cleaning
- Version: shelvesHousing: 3-sidedRim: at 3 sides

With handles

# Intended Use

As described below, every use of the appliance for a purpose differing and/or diverging from its intended standard use, is prohibited and considered to be an unintended use.

The following is an intended use:

- Cleaning and transporting dishes.
- Serving dishes.



## Accessories (not included in the delivery)

## Cleaning container set TSA300V

for serving trolley TSA300V

Waste container:

W 343 x D 230 x H 440 mm

Cutlery container:

W 333 x D 230 x H 173 mm

Weight: 2.0 kg
Art. No. 300061





Fig. 1

300055 5 / 10



# Scope of Delivery / Part Name

- 1. Unpack the serving trolley and remove the packing material pursuant to environmental regulations.
- 2. Check completeness of delivery according to the list below and Fig. 2:

| No. | Name                                   | Number |
|-----|--|--------|
| 1   | Handle                                 | 2x     |
| 2   | Top shelf                              | 1x     |
| 3   | Handle bolt                            | 4x     |
| 4   | Rear wall (large)                      | 2x     |
| 5   | Side wall (small)                      | 4x     |
| 6   | Spacer                                 | 8x     |
| 7   | Centre shelf                           | 1x     |
| 8   | Bottom shelf                           | 1x     |
| 9   | Swivel casters                         | 4x     |
| 10  | Cover (optional for 1-handle assembly) | 2x     |

# **B**artscher




Fig. 2

300055 7 / 10



#### **Assembly**

- 1. Under each shelf, check the marking for the bottom, centre or top shelves.
- 2. Start assembly with the bottom shelf (8, Fig. 2).
- 3. Place 4 spacers (6) in the corners of the bottom shelf.

#### NOTE!

Use a rubber mallet to hammer each spacer down until there are no gaps between the spacers and the corner fixings of the bottom shelf.



- 4. First, place the back wall (4), inserting it into the slots provided in the spacers (6).
- In the same way, fit the side walls (5) on the right and left sides into the spacers (6) (Fig. 3).
- Make sure that all the walls engage well in the slots.

Fig. 3

ΕN

- 7. Next, place the centre shelf (7) over the spacers (6).
- 8. Place 4 further spacers (6) in the corners of the centre shelf (7). Use a rubber mallet to fix the spacers correctly.
- 9. Repeat steps 4 and 5 to fix the back and side walls.
- 10. Before fitting the top shelf (2) to the serving trolley, fix both handles (1) onto it.
- 11. Secure the handles in the lower holes of the top shelf with the screws (3) provided.
- 12. Now, using a rubber mallet, fix the top shelf (2) with the handles (1) fitted onto the spacers (6).
- 13. If only one handle will be used instead of two, note the notch in the upper part see Fig. 1.
  - **A** optional covers (10) for the serving trolley with one handle.
  - **B** with handle screw when using covers.





- 14. Lay the serving trolley on its side.
- 15. Use a rubber mallet to fix the swivel casters (9) to the bottom shelf (8) of the serving trolley.
- 16. Place the serving trolley on the swivel casters.

Fig. 4

#### Loading the Serving Trolley

- 1. The serving trolley with 3 shelves can be used for serving, cleaning and transporting.
- 2. Place dishes, cutlery etc. on the shelves of the serving trolley as required.

Rims on the shelves prevent the transported items from slipping.

Thanks to the three-sided housing, the trolley hides transported items, such as dirty dishes, from view.



Fig. 5

300055 9 / 10

ΕN



#### Cleaning

#### **ATTENTION!**

For cleaning, do not use any scouring agents containing solvents nor corrosive cleaning agents. They may damage the surface.

- 1. Clean the serving trolley regularly with warm water and a soft, damp cloth. Use a mild cleaning agent when required.
- 2. Dry the serving trolley with a soft cloth.