

**3850 3E-K**



**700357**

**Technical specification**


<b>Name</b>	<b>Buffet cabinet 3850 3E-K</b>
Code-No.:	<b>700357</b>
Material:	Glass, stainless steel
Colour:	silver
Model:	<ul style="list-style-type: none"> <li>▪ Number of levels: 3</li> <li>▪ Size of surface: W 385 x D 265 x H 175 mm</li> <li>▪ Glass door size: W 400 x H 600 mm</li> <li>▪ Properties:               <ul style="list-style-type: none"> <li>- Insert shelves can be removed</li> <li>- Glass door with lock</li> </ul> </li> <li>▪ Operation: on reverse side</li> </ul>
Dimensions:	W 405 x D 335 x H 620 mm
Weight:	17.15 kg

We reserve the right to implement the technical modifications!

**Use as intended**

The buffet cabinet is intended for presentation of food that is not susceptible to temperature, such as biscuits, dry cakes, chocolates, filled buns and sandwiches. Products displayed on 3 levels, which saves room.

## Overview of parts



- 1 Top glass
- 2 Right side glass
- 3 Glass door with handle (from service side)
- 4 Magnet to close the door
- 5 Base unit
- 6 Glass shelf (3x)
- 7 Feet (4x)
- 8 Left side glass
- 9 Left side glass

## User instructions

- Unpack the buffet cabinet and remove the packing material according to the environmental regulations.
- The buffet cabinet should be thoroughly cleaned before the first use. Follow the instructions in section 6 “**Cleaning instructions**”.
- Place the buffet cabinet on an even surface.
- When placing, make sure there is enough space from service side to open the glass doors.
- Do not locate the buffet cabinet in the place exposed to the direct sunlight.
- Do not store perishable products in the buffet cabinet.
- Glass shelves are operated from the service side and can be removed, if necessary.
- Prepare appropriate food products and place them on the shelves.



- To remove the presented food products, open the glass door from the service side.

- To close the glass door, there is a magnet on the middle shelf fixing that attracts the handle and holds the glass door shut.



## Cleaning instructions

- To clean the device, remove the shelves.
- Clean the shelves and interior and exterior of the buffet cabinet with a soft, wet, lint-free cloth.
- In case of strong contamination, use a mild cleaning agent.
- **Never** use harsh or coarse cleaning agent which may scratch the surface of the buffet cabinet.

Bartscher GmbH  
Franz-Kleine-Str. 28  
33154 Salzkotten  
Germany

phone: +49 5258 971-0  
fax: +49 5258 971-120  
**Service-Hotline:** +49 5258 971-197  
[www.bartscher.com](http://www.bartscher.com)