



- P1 Stecker/Plug
- TH1 Thermostat
- C1 Kompressor/Compressor
- OF1 Überlastung/Overload
- R1 Relais/Relay
- SQ1 Temperaturfühler/Temperature probe
- F1 Kondensatorlüfter/Condenser fan
- F2 Verdampferlüfter/Evaporator fan
- F3 Verdampferlüfter/Evaporator fan
- F4 Verdampferlüfter/Evaporator fan
- TR1 Transformator/Transformer
- L1 Lampe/Lamp