

GB

**Care and Cleaning Instructions
Drip Trays Z50-150 / Z50-170,
Art. No.: 190215 / 190216**

ATTENTION!

Never use caustic nor harsh cleaning agents, which may damage the surface of drip trays and drip grates.

Never wash drip trays in a dishwasher.

- Remove the drip grate.
- Empty the drip tray.
- Prior to first use and after each subsequent use clean the drip tray and drip grate thoroughly, using warm water, soft cloth or sponge and mild cleaning agent.
- To end with, rinse the drip tray and drip grate a few times with fresh water.
- Wipe the drip tray and drip grate with a soft cloth.

Bartscher GmbH
Franz-Kleine-Str. 28
33154 Salzkotten
Germany

Phone: +49 5258 971-0
Fax: +49 5258 971-120
Service hotline: +49 5258 971-197
www.bartscher.com