

CT 100**200.2010****CT 200****200.2020****Bedienungsanleitung****Pizzaofen**

Seite 3 bis 16

D/A/CH**Instruction manual****Pizza oven**

from page 17 to 30

GB/UK**Mode d'emploi****Four à pizza**

de page 31 à page 44

F/B/CH

**Keep this instruction manual
ready to hand at the product!**

1. General Information	18
1.1 Information about the instruction manual	18
1.2 Key to symbols	18
1.3 Liability and Warrantees	19
1.4 Copyright protection	19
1.5 Declaration of conformity	19
2. Safety	20
2.1 General information	20
2.2 Safety instructions for use of the device	20-21
2.3 Intended use	21
3. Delivery, packaging and storage	22
3.1 Delivery check	22
3.2 Packaging	22
3.3 Storage	22
4. Technical data	23
4.1 Overview of parts	23
4.2 Technical specification	24
5. Installation and operation	25
5.1 Safety instructions	25
5.2 Installation and connection	26
5.3 Operating	27
6. Cleaning and maintenance	28
6.1 Safety advice	28
6.2 Cleaning	28
6.3 Safety instructions for maintenance	28
7. Possible Malfunctions	29
8. Waste disposal	30

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120

1. General information

1.1 Information about the instruction manual

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

1.2 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



WARNING!

This symbol highlights hazards, which could lead to injury.

Please follow the instructions very carefully and proceed with particular attention in these cases.



WARNING! Electrical hazard!

This symbol draws attention to potential electrical hazards. If you do not follow the safety instructions, you may risk injury or death.



CAUTION!

This symbol highlights instructions, which should be followed to avoid any risk of damage, malfunctioning and/or breakdown of the device.



NOTE!

This symbol highlights tips and information, which have to be followed for an efficient and trouble-free operation of the device.



WARNING! Hot external surface!

This symbol is a warning that the device surface is hot when in use. Ignoring this warning may result in burns!

1.3 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology. If you have any questions, you should contact the manufacturer.



NOTE!

Read the instruction manual carefully before using the device. The manufacturer does not accept liability for any damage or malfunction resulting from not following the instructions for use.

The instruction manual should be kept near the device, easily accessible for anyone wishing to work with or using it. We reserve the right to make technical changes for purposes of developing and improving the useful properties.

1.4 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



NOTE!

The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.

1.5 Declaration of conformity

The device complies with the current standards and directives of the EU.

We certify this in the EC declaration of conformity.

If required we will be glad to send you the according declaration of conformity.

2. Safety

This section provides an overview of all important safety aspects.

In addition every chapter provides precise safety advice for the prevention of dangers which are highlighted by the use of the above mentioned symbols.

Furthermore, attention should be paid to all pictograms, markers and labels on the device, which must be kept in a permanent state of legibility.

By following all the important safety advice you gain an optimal protection against all hazards as well as the assurance of a safe and trouble-free operation.

2.1 General Information

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

Knowing the contents of the instruction manual as well as avoiding mistakes and thus operating this device safely and in a fault-free manner is very essential to protect yourselves from the hazards.

To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.

This device may only be operated in technically proper and safe condition.

2.2 Safety instructions for use of the device

The specifications regarding the industrial safety are based on the Regulations of the European Union applicable at the time of manufacturing the device.

If the device is used commercially, the user is obliged to ensure that the said industrial safety measures concur with the state of the rules and regulations applicable at the time in question for the entire period of use of the device and to comply with the new specifications.

Outside the European Union, the industrial safety laws applicable at the place of installation of the device and the regional territorial provisions must be complied with.

Besides the industrial safety instructions in the instruction manual, the general safety and accident prevention regulations as well as environment protection regulations applicable for area of application of the device must be followed and complied with.



CAUTION!

- The device is not intended for use by individuals (including children) with physical or mental disabilities, insufficient experience, and/or insufficient knowledge unless such persons are under the care of a person responsible for their safety or have received instructions regarding appropriate use of the device.
- Children should be observed to ensure that they are not playing with the device.
- Preserve this manual safely. When passing on/selling the device to a third party, the manuals must be handed over along with the device.
- Every person using the device must act in accordance to the manuals and under consideration of the safety advice.
- The device is to be used indoors only.

2.3 Intended use



CAUTION!

This device has been designed for commercial use only and must be operated by qualified kitchen personnel only.

Safe operation is only guaranteed when using the device for its intended purpose.

Any technical interventions, as well as assembly and maintenance are to be made by a qualified customer service only.

The **pizza oven** is **exclusively** intended for **pizza baking**.

The **pizza oven** shall **not** be used for:

- Baking cake, bread, bread rolls and similar kinds of pastry;
- Preparing or warming up the food dishes.



CAUTION!

Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.

Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.

The operator is liable for all damages resulting from inappropriate use.

3. Transport, packaging and storage

3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt.

In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



NOTE!

If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

3.3 Storage

Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.

Packages should be stored under consideration of the following:


- Do not store outdoors.
- Keep it dry and dust-free.
- Do not expose it to aggressive media.
- Do not expose it to direct sunlight.
- Avoid mechanical shocks and vibration.
- In case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly. If required refresh or renew.

4. Technical data

4.1 Overview of parts



Control Panel



4.2 Technical specifications

Description:	Pizza oven	
Model:	CT 100	CT 200
Item no.:	200.2010	200.2020
Temperature range:	50°- 400°C	
Connection:	3 NAC 380V 50 Hz	
Power:	4200 W	8400 W
Dimensions:	W 890 x D 880 x H 430 mm	W 890 x D 880 x H 750 mm
Dimensions Baking chamber:	W 610 x D 610 x H 140 mm	2 x W 610 x D 610 x H 140 mm
Capacity:	4 Pizzas Ø 30 cm	2 x 4 Pizzas Ø 30 cm
Weight:	68 kg	98 kg

Subject to technical changes and alterations!

Additional accessories (not included in the packaging)

	<p>Base unit Pizza oven CT 100 and CT 200</p> <p>Stainless steel W 895 x D 735 x H 900 mm Weight: 17 kg</p> <p>Code-No.: 200.315</p>
--	--

5. Installation and operation

5.1 Safety instructions



WARNING! Electrical hazard!

The device must only be connected to a properly installed single socket with protective contact.

Never yank cord to disconnect from outlet.

Cable must not touch any hot parts.

- See that the cable does not touch any heat sources or sharp edges. Do not let the cable dangle over the counter edge.



WARNING! Hot surface!

During operation some elements of the device very become hot. To avoid burns, do not touch hot elements!

- Do not use the device in case it does not function properly, has been damaged or dropped.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- Do not lay the cable over carpets or heat insulations. Do not cover the cable. Keep away the cable from operating range and do not dunk it into water.
- In the event of thunder storms (lightning etc.) immediately switch off the power supply. This will prevent damage to the appliance caused by strokes of lightning.



WARNING! Hazard via electrical current!

The device can cause injuries due to improper installation!

Before installation the local power grid specification should be compared with that of the device (see type label).

Connect the device only in case of compliance!

Take note of the security advice!

5.2 Installation and connection



CAUTION!

The installation and maintenance of the appliance should only be carried out by trained personnel!

- Discard the complete packing material after unpacking the device.
- Remove the protective foil from the appliance. Ensure that it has been completely removed.
- Place the device on top of an even and safe surface which supports the weight of the device and is not heat sensitive.
- Not **at any time** should you place the device on an inflammable surface (such as: table cloth, carpet, etc.).
- You must not position the device near open fireplaces, electric ovens/arc furnaces, furnaces/electric heaters or other heat sources.



NOTE!

This appliance is not suitable for built-in use nor for being set up in multiple in-line series.

- Place the appliance in well-ventilated rooms.
- Keep a minimum safety distance of at least 20 cm to walls or other objects.
- Arrange the appliance so that the power plug and control panel are easily accessible.
- Do not place inflammable acidic or alkaline materials or cloths close to the appliance since this may reduce the operational life of the appliance and may involve the danger of deflagration.
- The rear side of the appliance is fitted with an earthing pin. Please connect the earthing cable to a copper wire (minimum diameter 2 mm²) in accordance with the generally applicable safety regulations.

5.3 Operating

- Connect the appliance to a single, earthed power socket.
- Switch on the appliance using the **ON/OFF** switch.
- The temperature may be regulated separately by means of the temperature controls for each baking chamber.
- Each baking chamber has two heating elements, which can be regulated by the temperature control for top and bottom heat. The pilot lamps will light up accordingly.
- Select the desired temperature.
- The controllable temperature range of the pizza oven is from 50°- 400°C. The recommended temperature is between 300°- 400°C.
- When the set temperature has been reached, the pilot lamp goes out.



NOTE!

Always pre-heat the pizza oven before baking pizzas!

- Open the door of the pizza oven using the door handle.
- Place the pizzas (max. 4 pizzas Ø 30 cm) in the baking chamber of the pizza oven and close the oven door.
- Do not leave the pizzas unattended during the baking process.
- Keep an eye on the baking process through the glass window.



CAUTION!

Do not open the door of the pizza oven during operation!

- When the pizza is ready, switch off the appliance and only then open the door.
- Remove the baked pizza from the oven.



WARNING! Danger of burns!

During operation some parts of the appliance get very hot. Do not touch these parts with bare fingers or hands. Wear protective gloves which cover the wrists when removing pizzas from the oven and use the appropriate kitchen utensils with long handles in order to avoid burns.

- On completion of the baking process, turn the temperature control anti-clockwise to the „0“ mark. Switch off the appliance with the ON /OFF switch.
- Disconnect the appliance from the power socket (pull the power plug!!!) if it is no longer to be used.

6. Cleaning and maintenance

6.1 Safety advice

- Before beginning with repair or cleaning works make sure the device has been disconnected from power socket (pull the power plug!!!) and has cooled down.
- Do not use any acid agents and make sure no water ingresses the device.
- To protect yourself from electric shock, **never** immerse the device, its cables and the plug in water or other liquids.



CAUTION!

The device is not suited for direct washing via water jets. Therefore, you must not use any kind of pressure water jet for cleaning the device!

6.2 Cleaning

- The device should be cleaned regularly.
- Clean the outer housing of the appliance, the oven chambers and the baking stone with a soft, damp cloth and a mild detergent.
- Apply a final wipe with a clean cloth to remove residues of cleaning agents.
- Do not use caustic cleaning agents to clean the appliance.
- Use soft cloth only and make sure you **never** use any kind of abrasive agents, which could scratch the surface.
- After the cleaning procedure you should use a soft and dry cloth to wipe dry and polish the surface.

6.3 Safety instructions for maintenance

- Check the mains connection cable for damage from time to time. Never operate the device when the cable is damaged. A damaged cable must immediately be replaced by customer service or a qualified electrician to avoid dangers.
- In case of damage or malfunction, please contact your stockist or our customer service centre. Pay attention to the troubleshooting tips in pt. 7.
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. **Do not attempt to repair the device yourself.**

7. Possible Malfunctions

Problem	Cause	Solution
Power socket connected, power on, power control lamp on, but appliance does not heat up.	<ul style="list-style-type: none">• Thermostat defective.• Heating element burnt out.	<ul style="list-style-type: none">• Contact retailer• Contact retailer
Power on, temperature control set, temperature rises but cannot be regulated (selected).	<ul style="list-style-type: none">• Temperature control defective	<ul style="list-style-type: none">• Contact retailer
Power on, appliance switched on, but control lamp does not come on.	<ul style="list-style-type: none">• Control lamp defective.	<ul style="list-style-type: none">• Contact retailer
Power on, control lamp does not come on and the appliance does not heat up.	<ul style="list-style-type: none">• Power supply not working properly, no voltage.• The fuse is blown.	<ul style="list-style-type: none">• Check power supply and cable connection.• Contact retailer

The above mentioned problem cases are exemplary and just meant for orientation. If these or similar problems should occur, switch off the device immediately and stop the use. Contact qualified professionals or your retailer for further inspection and repairs.

8. Waste disposal

Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



WARNING!

To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.



NOTE!



For the disposal of the device please consider and act according to the national and local rules and regulations.

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120