



**A150512**

**ENGLISH**

**Table of contents**

**1. Safety ..... 16**  
1.1 Key to symbols ..... 16  
1.2 Safety instructions ..... 17  
1.3 Proper use ..... 21

**2. General information ..... 22**  
2.1 Liability and Warrantees ..... 22  
2.2 Copyright protection ..... 22  
2.3 Declaration of conformity ..... 22

**3. Transport, packaging and storage..... 23**  
3.1 Delivery check ..... 23  
3.2 Packaging..... 23  
3.3 Storage..... 23

**4. Technical data ..... 24**  
4.1 Overview of parts ..... 24  
4.2 Technical specification ..... 25

**5. Installation and operation..... 25**  
5.1 Installation ..... 25  
5.2 Operation..... 26

**6. Cleaning ..... 27**

**7. Waste disposal ..... 28**

Bartscher GmbH  
Franz-Kleine-Str. 28  
33154 Salzkotten  
Germany

phone: +49 5258 971-0  
fax: +49 5258 971-120  
**Service-Hotline:** +49 5258 971-197  
www.bartscher.com



**Read this instruction manual before using and keep them available at all times!**

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

Please keep these instructions and give them to future owners of the device.

## 1. Safety

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

All persons using the device must follow the recommendations and instructions in this instruction manual.

### 1.1 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



**WARNING!**

This symbol highlights hazards which could lead to injury.



**WARNING!**

This symbol highlights dangerous situations which could lead to injury or death.



### **HOT SURFACE!**

This symbol is a warning that the device surface is hot when in use. Ignoring this warning may result in burns!



### **CAUTION!**

This symbol highlights dangerous situations which could lead to light injuries, or damage, malfunction, and/or destruction of the device.



### **NOTE!**

This symbol highlights recommendations and information aimed for effective and trouble-free device operation.

## **1.2 Safety instructions**

- The device can be used by children 8 years and up, as well as by people with disabilities and those with limited experience/knowledge as long as they are under supervision or have been instructed on proper use of the device and its possible dangers. Children should not play with the device. Cleaning and maintenance cannot be performed by children younger than 8 years old and must be done under supervision. Children under the age of 8 years old must be kept away from the device and its power cord.
- **Never** leave the device unattended when in use.
- Only use the device indoors.
- The device must be operated in correct and safe technical condition only. In case of operational problems disconnect the device from the power supply (pull the plug from the socket) and contact the service company.

- Prevent access of children to the package materials like plastic bags and foamed polystyrene elements. **Suffocation hazard!**
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. **Do not attempt to repair the device yourself.**
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.



## **DANGER! Electric shock hazard!**

To avoid the hazard results please follow the safety instructions below.

- Never allow the power cable to come into contact with heat sources or sharp edges. The power cable should not hang over the side of the working surface. Ensure that no one can step on or trip over the cable.
- The power cable must not be folded, bent or tangled, and must always remain fully unrolled. Never place the device or other objects on the power cable.
- Do not cover the cable. Keep away the cable from operating range.

- Check the power cord regularly for damage. Do not use the device if the power cord is damaged. If this cable is damaged, it must be replaced by customer service or a qualified electrician in order to avoid dangers.
- The supply cable must be disconnected from the socket only by pulling the plug.
- Never carry or lift the device by the supply cable.
- In any case do not open the device housing. In case of electrical or mechanical modifications the **electric shock hazard** will occur.
- Never immerse the device, the power cord and the power plug in water or other liquids.
- Do not use any acid agents and make sure no water ingresses the device.
- **Never** operate the device with moist hands or standing on wet floor.
- Remove the plug from its socket:
  - when the device is not used,
  - in case of anomalies during operation,
  - before cleaning.



### **HOT SURFACE! Burn hazard!**

To avoid the hazard results please follow the safety instructions below.

- During the operation and directly after its completion, the inner lid and inner pot are very hot. Do not touch these surfaces with bare hands. To open the lid use its handles and in order to remove the inner pot use the handles of this pot.

- When opening the lid, the escaping steam of the hot rice may scald fingers, hands. Be careful when opening the lid.
- Never tilt or move a hot, filled rice warmer.



## **WARNING! Hazardous to health!**

To avoid the hazard results please follow the safety instructions below.

- Never place cold or cooled rice in the pre-heated rice warmer, but only hot or cooked one.
- Never add freshly cooked rice to the rice which has been kept in the rice warmer longer than for the recommended 12 hours.
- Never keep rice in the rice warmer longer than for the maximum recommended time of twelve hours. After exceeding this time of warming, the rice should be utilized. **Do not serve such rice**, as it is already unfit for consumption.
- Wash the inner pot and inner lid regularly and thoroughly to prevent development of harmful germs.



## **CAUTION!**

**In order to avoid any damages of the device follow the instructions below.**

- Do not use abrasive or acid agents to clean inner and outer pots as these may damage the surface of the device elements.
- Never immerse the device in water or other fluids. Never pour water to the external pot and remember that it should be dry and clean before placing the inner pot in it.

### 1.3 Proper use

The operational safety of the device is assured only in case of proper use, according to the operation manual.

All technical activities like installation and maintenance must be performed by the qualified service personnel only.

The device is intended for home use or in similar places such as:

- in kitchens for store or office employees or in similar business areas;
- in agricultural farms;
- by guests of hotels, motels and other typical places of accomodation;
- in Bed and Breakfast facilities.

The **rice warmer** is designed only for **keeping the temperature of the cooked rice**,

The **rice warmer** must **not** be used for:

- warming cold rice,
- warming and keeping warm soups, water or other foods, fluids;
- filling and warming of flammable, noxious or volatile fluids or materials, etc.



#### **CAUTION!**

**Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.**

**Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.**

**The operator is liable for all damages resulting from inappropriate use.**

## 2. General information

### 2.1 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology.



#### **CAUTION!**

**Read this manual carefully and thoroughly before any operation of the device, and especially before turning it on!**

Manufacturer **is not liable** for any damages or faults caused by:

- violation of advice concerning operation and cleaning;
- use other than designed;
- alterations made by user;
- use of inadequate spare parts.

We reserve the right to make technical changes for purposes of developing and improving the useful properties.

### 2.2 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



#### **NOTE!**

**The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.**

### 2.3 Declaration of conformity



The device complies with the current standards and directives of the EU. We certify this in the EC declaration of conformity. If required we will be glad to send you the according declaration of conformity.

## 3. Transport, packaging and storage

### 3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt. In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

### 3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



**If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.**

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

### 3.3 Storage

Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.

Packages should be stored under consideration of the following:

- do not store outdoors,
- keep it dry and dust-free,
- do not expose it to aggressive media,
- do not expose it to direct sunlight,
- avoid mechanical shocks and vibration,
- in case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly, if required refresh or renew.

## 4. Technical data

### 4.1 Overview of parts



- 1 Snap lock
- 2 Inner lid
- 3 Supporting pin of the inner lid
- 4 Outer lid
- 5 Outer pot
- 6 Outer pot handle
- 7 Inner pot
- 8 Inner port handle
- 9 Stirring spoon
- 10 Rice spoon

## 4.2 Technical specification

Description	Rice warmer with surround heating
Code-no.:	<b>A150512</b>
Material body:	stainless steel
Inner pot:	non-stick coating, heat resistant
Power:	110 W / 220-240 V 50/60 Hz
Capacity (inner pot)	8.5 kg of rice – boiled
Dimensions:	W 395 x D 395 x H 372 mm
Weight:	7.9 kg
Accessories:	1 rice spoon, 1 stirring spoon

We reserve the right to make technical changes!

## 5. Installation and operation

### 5.1 Installation

#### Positioning

- Unpack the device and remove all packing material.



#### **CAUTION!**

**Never remove the rating plate and any warning signs from the device.**

- Place the device on top of an even, stable, dry, and water-resistant surface which supports the weight of the device and is not heat sensitive.
- **Never** place the device at the edge of a table to avoid accidents.
- **Never** place the device in humid or wet environment.
- **Never** place the device on the flammable surfaces.
- Place the device so that the plug is easily accessible and can be quickly removed from its socket in case of necessity.

## Connection



**DANGER! Electric shock hazard!**

**The device can cause injuries due to improper installation! Before installation and connecting the local power grid specification should be compared with that of the device (see rating plate). Connect the device only in case of compliance!**

- The power supply circuit with the socket must be protected by the fuse of at least 16A. Connect the device directly to a single grounded socket. Do not use any power bar or multiple socket.

## 5.2 Operation

### Before the first use

- Before the first use, clean the device according to the instructions included in section 6 "Cleaning".



**CAUTION!**

**Before the first use of the rice warmer, make sure that the inner pot and outer pot are dry and clean.**

### Keeping rice warm

- Place the inner pot in the outer pot and close the lid.
- Connect the plug to a grounded single socket.
- The red power indicator near the lid's hinges will come on.

Power indicator (red)



**CAUTION!**

**Before filling in the rice, always pre-heat the device for approx. 30 minutes.**

- After pre-heating, fill the **hot cooked** rice into the inner pot and close the lid of the rice warmer.
- The rice may be kept warm at approx. 65°C for **about 12 hours**, provided that the rice had been filled in hot.



#### **NOTE!**

The rice warmer **is not** designed for heating cold rice.

- **Do not** disconnect the device from the power supply (e.g. do not pull the plug) during the operation.
- After heating, disconnect the device from the power supply (pull the plug!).

## 6. Cleaning



### **WARNING!**

**Before cleaning, disconnect the device from the power supply (unplug!) and leave to cool off.**

**Never clean the device with use of pressurized water jet.  
Protect the device from the water penetration.**

- Clean the device daily.
- Before cleaning, leave the device to cool off.
- Remove the inner pot from the outer pot and remove the inner lid from the supporting pin. Clean the inner pot and inner lid thoroughly with warm water with mild cleaning agent. Rinse with fresh water and wipe dry with a soft cloth.
- Clean the inside and the outside of the outer pot and the outer lid with a soft, damp cloth. Wipe it dry afterwards.
- Place the inner pot in the rice warmer and mount the inner lid on the supporting pin.
- Use soft cloths only, **never** use abrasive pads which may scratch the surface of the device.

## Storage

- If the device is not used for any lengthy period, clean it according to the aforementioned description and store it in dry, clean place protected against cold, sun and children. Do not place any have objects on the device.

## 7. Waste disposal

### Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



### **WARNING!**

**To exclude any abuse and the dangers involved make the waste device unfit for use before disposal.**

**For that purpose disconnect device from mains supply and remove mains connection cable from the device.**



**For the disposal of the device please consider and act according to the national and local rules and regulations.**

Bartscher GmbH  
Franz-Kleine-Str. 28  
33154 Salzkotten  
Germany

phone: +49 5258 971-0  
fax: +49 5258 971-120  
**Service-Hotline:** +49 5258 971-197  
[www.bartscher.com](http://www.bartscher.com)