

**203.510****203.500****Bedienungsanleitung
Pizzabacköfen „Mini“**

Seite 3 bis 15

D/A/CH

**Instruction manual
Pizza oven „Mini“**

from page 17 to 29

GB/UK

**Mode d'emploi
Four à pizza „Mini“**

de page 31 à page 43

F/B/CH

**Keep this instruction manual
ready to hand at the product!**

1. General Information	18
1.1 Information about the instruction manual	18
1.2 Key to symbols	18
1.3 Liability and Warrantees	19
1.4 Copyright protection	19
1.5 Declaration of conformity	19
2. Safety	20
2.1 General information	20
2.2 Safety instructions for use of the device	20-21
2.3 Intended use	21
3. Delivery, packaging and storage	22
3.1 Delivery check	22
3.2 Packaging	22
3.3 Storage	22
4. Technical data	23
4.1 Technical specification	23
4.2 Overview of parts	23-24
5. Installation and operation	25
5.1 Safety instructions	25
5.2 Installation and connection	26
5.3 Operating	26-27
6. Cleaning and maintenance	28
6.1 Safety advice	28
6.2 Cleaning	28
6.3 Safety instructions for maintenance	29
7. Waste disposal	29

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120

1. General information

1.1 Information about the instruction manual

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

1.2 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



WARNING!

This symbol highlights hazards, which could lead to injury.

Please follow the instructions very carefully and proceed with particular attention in these cases.



WARNING! Electrical hazard!

This symbol draws attention to potential electrical hazards. If you do not follow the safety instructions, you may risk injury or death.



CAUTION!

This symbol highlights instructions, which should be followed to avoid any risk of damage, malfunctioning and/or breakdown of the device.



NOTE!

This symbol highlights tips and information, which have to be followed for an efficient and trouble-free operation of the device.



WARNING! Hot external surface!

This symbol is a warning that the unit surface is hot when in use. Ignoring this warning may result in burns!

1.3 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology. If you have any questions, you should contact the manufacturer.



NOTE!

Read the instruction manual carefully before using the device. The manufacturer does not accept liability for any damage or malfunction resulting from not following the instructions for use.

The instruction manual should be kept near the device, easily accessible for anyone wishing to work with or using it. We reserve the right to make technical changes for purposes of developing and improving the useful properties.

1.4 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



NOTE!

The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.

1.5 Declaration of conformity

The device complies with the current standards and directives of the EU.

We certify this in the EC declaration of conformity.

If required we will be glad to send you the according declaration of conformity.

2. Safety

This section provides an overview of all important safety aspects.

In addition every chapter provides precise safety advice for the prevention of dangers which are highlighted by the use of the above mentioned symbols.

Furthermore, attention should be paid to all pictograms, markers and labels on the device, which must be kept in a permanent state of legibility.

By following all the important safety advice you gain an optimal protection against all hazards as well as the assurance of a safe and trouble-free operation.

2.1 General Information

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

Knowing the contents of the instruction manual as well as avoiding mistakes and thus operating this device safely and in a fault-free manner is very essential to protect yourselves from the hazards.

To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.

This device may only be operated in technically proper and safe condition.

2.2 Safety instructions for use of the device

The specifications regarding the industrial safety are based on the Regulations of the European Union applicable at the time of manufacturing the device.

If the device is used commercially, the user is obliged to ensure that the said industrial safety measures concur with the state of the rules and regulations applicable at the time in question for the entire period of use of the device and to comply with the new specifications.

Outside the European Union, the industrial safety laws applicable at the place of installation of the device and the regional territorial provisions must be complied with.

Besides the industrial safety instructions in the instruction manual, the general safety and accident prevention regulations as well as environment protection regulations applicable for area of application of the device must be followed and complied with.



CAUTION!

- The unit is not intended for use by individuals (including children) with physical or mental disabilities, insufficient experience, and/or insufficient knowledge unless such persons are under the care of a person responsible for their safety or have received instructions regarding appropriate use of the unit.
- Children should be observed to ensure that they are not playing with the unit.
- Preserve this manual safely. When passing on/selling the device to a third party, the manuals must be handed over along with the device.
- Every person using the device must act in accordance to the manuals and under consideration of the safety advice.
- The device is to be used indoors only.

2.3 Intended use



CAUTION!

This device has been designed and built for commercial use only and should be operated by qualified personnel only.

Safe operation is only guaranteed when using the device for its intended purpose.

Any technical interventions, as well as assembly and maintenance are to be made by a qualified customer service only.

The pizza oven is intended only for baking pizza.



CAUTION!

Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.

Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.

The operator is liable for all damages resulting from inappropriate use.

3. Transport, packaging and storage

3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt.

In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



NOTE!

If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

3.3 Storage

Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.

Packages should be stored under consideration of the following:

- Do not store outdoors.
- Keep it dry and dust-free.
- Do not expose it to aggressive media.
- Do not expose it to direct sunlight.
- Avoid mechanical shocks and vibration.
- In case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly. If required refresh or renew.

4. Technical data

4.1 Technical specification


Name	Pizza oven	
Model:	„Mini 1“	„Mini 2“
Art.no.:	203.510	203.500
Construction:	Stainless steel	
Power:	230 V ~ 50 Hz 2000 W	230 V ~ 50 Hz 3000 W
Temperature range:	to 300 °C	
Time range:	0 - 15 min. / continuous use	
Dimensions:	W 550 x D 430 x H 245 mm	W 550 x D 430 x H 375 mm
Baking chamber:	W 410 x D 370 x H 90 mm	W 410 x D 370 x H 90 mm
Weight:	18 kg	34 kg


We reserve the right to make technical changes!

4.2 Overview of parts

203.510

- ① Casing
- ② Ventilation ducts
- ③ Temperature dial
- ④ Green control light
- ⑤ Time regulator
- ⑥ Orange power light
- ⑦ Door
- ⑧ Adjustable legs
- ⑨ Door handle





- ① Casing
- ② Ventilation ducts
- ③ Upper chamber temperature dial
- ④ Upper chamber activation light (green)
- ⑤ Upper chamber standby light (orange)
- ⑥ Upper chamber time dial
- ⑦ Lower chamber temperature dial
- ⑧ Lower chamber activation light (green)
- ⑨ Standby light (orange)
- ⑩ Lower chamber time dial
- ⑪ Adjustable legs
- ⑫ Lower chamber door
- ⑬ Lower chamber door handle
- ⑭ Upper chamber door
- ⑮ Upper chamber door handle

5. Installation and operation

5.1 Safety instructions



WARNING! Electrical hazard!

The device must only be connected to a properly installed single socket with protective contact.

Never yank cord to disconnect from outlet.

Cable must not touch any hot parts.

- See that the cable does not touch any heat sources or sharp edges. Do not let the cable dangle over the counter edge.



WARNING! Hot external surface!

During operation some elements of the unit very become hot. To avoid burns, do not touch hot elements!

- Do not use the device in case it does not function properly, has been damaged or dropped.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- Do not lay the cable over carpets or heat insulations. Do not cover the cable. Keep away the cable from operating range and do not dunk it into water.
- Do not move or tilt the device when in operation.



WARNING! Hazard via electrical current!

The device can cause injuries due to improper installation!

Before installation the local power grid specification should be compared with that of the device (see type label).

Connect the device only in case of compliance!

Take note of the security advice!

5.2 Installation and connection



CAUTION!

The installation and maintenance of the appliance should only be carried out by trained personnel!

- Discard the complete packing material after unpacking the device.
- Carefully remove the protective foil from internal surfaces to avoid leaving any adhesive tape. If any adhesive tape does remain stuck, remove it using an appropriate agent.
- Place the device on top of an even and safe surface which supports the weight of the device and is not heat sensitive.
- Not **at any time** should you place the device on an inflammable surface (such as: table cloth, carpet, etc.).
- You must not position the device near open fireplaces, electric ovens/arc furnaces, furnaces/electric heaters or other heat sources.
- Do not place the unit near walls or other objects made of flammable materials. Keep a minimum distance of 20 cm on all sides of the unit.
- The unit is equipped with adjustable legs to help it rest evenly. They should be used to place the unit in a level position.
- Place the unit in a well-ventilated area.
- Place the unit under a kitchen hood to remove steam and odours.
- **Never** cover the pizza oven with towels or cloths, **do not** hang any objects on the unit.
- The unit can be installed separately or in a series along with other units.
- The electrical circuit in the socket must be secured to at least 16A. Only connect the unit directly to the wall socket; do not use any extension cords or power strips.
- Position the device in a way so that the power plug is always accessible.

5.3 Operating

- Clean the unit prior to first use (see **6.2 Cleaning**).
- Connect the unit to an appropriate single-plug outlet.
- Prior to placing food in the unit, turn it on at maximum power for approx. 20-25 minutes in a very well ventilated area.



CAUTION!

Always preheat the unit for 20-25 min. before using!

- To turn the unit on, turn the time regulator clockwise to a position between 0 and 15 minutes. When the orange control light comes on, the unit is turned on and working.
- If the unit is to work for an extended time, turn the time regulator to the left, to the **ON** position. Then the time can be set properly prior to baking.
- Set the desired temperature (50°C – 300°C) by turning the temperature dial clockwise.
- When using the dual chamber pizza oven (**203.500**), please remember that by setting the upper chamber's temperature you are only setting the upper heating temperature. If you wish to use the lower heating at the same time, turn it on using the time dial and set the proper temperature using the temperature dial. The heater located under the bottom plate of the upper chamber serves as both the upper heater for the lower chamber and the lower heater for the upper chamber.
- When using the upper chamber, remember that the upper chamber time dial turns off only the upper heater. The temperature and time dials for the bottom chamber should be used to turn off the lower heater.



NOTE!

If you are using only one chamber, select the lower chamber as the temperature and time dials turn on both the upper and lower heaters.

- After reaching the desired temperature the green control light goes off.



WARNING! Danger of burns!

The external surface of the pizza oven gets very hot when in use. Do not touch it with bare hands. Use protective gloves or kitchen towels when opening and closing the door. Always use the handle to open and close the door!

- Open the pizza oven door and place the prepared pizza on the baking surface.
- Set the desired time. When the time expires, the unit automatically deactivates itself.
- Remove the pizza from the oven.
- Turn the unit off (the time regulator should be set to the „0“ position), and if the unit is not to be used again, remove the plug from its socket.

6. Cleaning and maintenance

6.1 Safety advice

- Before beginning with repair or cleaning works make sure the device has been disconnected from power socket (pull the power plug!!!) and has cooled down.
- Do not use any acid agents and make sure no water ingresses the device.
- To protect yourself from electric shock, **never** immerse the device, its cables and the plug in water or other liquids.



CAUTION!

The device is not suited for direct washing via water jets. Therefore, you must not use any kind of pressure water jet for cleaning the device!

6.2 Cleaning

- Clean the unit regularly.
- Clean the unit and leave it to cool.
- Clean with special care those elements of the unit which have contact with foodstuffs.
- The baking surface (ceramic plate) must be cleaned following every use with a metal scraper or other suitable implement.



ATTENTION!

Do not clean the ceramic plate when cold, nor with water, as it may be damaged.

- To thoroughly clean the ceramic plate, it may be removed after the unit has completely cooled.
- Check the ventilation ducts in the casing regularly and clean as needed, to correct the flow of air inside the unit.
- Always only use a soft cloth. **Never** use any kind of sharp cleaners which could scratch the unit.
- After cleaning, a soft, dry cloth should be used to dry and polish the surface.

6.3 Safety instructions for maintenance

- Check the mains connection cable for damage from time to time. Never operate the device when the cable is damaged. A damaged cable must immediately be replaced by customer service or a qualified electrician to avoid dangers.
- In case of damage or malfunction, please contact your stockist or our customer service centre.
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. **Do not attempt to repair the device yourself.**

7. Waste disposal

Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



WARNING!

To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.



NOTE!



For the disposal of the device please consider and act according to the national and local rules and regulations.

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120